



HardieTex Notes:

- ① HardieTex to be packed out over top of window and to be flush with brick veneer.
- ② Seal & mesh joints between HardieTex sheets. HardieTex & brick veneer. Mesh to extend 100mm past joints.
- ③ Apply sealer coat over HardieTex to ensure even adhesion across HardieTex & Joints
- ④ Apply further skim coat over whole area with MASONS PLASTABRICK MESHING RENDER (MR)
- ⑤ Continue plastering using base coat & finishing plaster to effect same texture over window head & wall.

**WINDOW HEAD - HARDIETEX, XRV
or ENVIRO Panel**

Detail 14 Scale: 1:20

Masonry Render System - Brick Veneer (Timber Framing)