



# ULLTRACLAD<sup>©</sup>

## Aluminium Cladding

ULLRICH ALUMINIUM CO LTD



**BRANZ Appraised**

Appraisal No.487 [2006]

# Contents

1.0	General information	2
2.0	Design information	4
3.0	Installation information	7
4.0	Maintenance	11
5.0	Health and safety	12

# 1.0 General information

## 1.1 Introduction

The Ulltraclad® Cavity System is a cavity-based, inter-locking powder coated aluminium weatherboard system. It is designed to be used as an external wall cladding system for residential and light commercial type buildings where domestic construction techniques are used.

The system includes horizontally fixed Ulltraclad® aluminium weatherboards, timber cavity battens, internal and external corner mouldings, starter strips, board jointers, board locators, joinery flashings and accessories.

Ulltraclad® aluminium weatherboards are produced in a rusticated weatherboard profile, with either a smooth (Standard), corrugated (Baby Corro) or grooved (Tee Board and Vertical Plank) face and are powder coated on the exposed surfaces. When installed, the cladding is effectively 15 mm thick. Standard and Baby Corro and Vertical Plank weatherboards are available 190 mm wide and are supplied 5 m and 6 m long. Tee Boards are available 150 mm wide and are supplied 5 m and 6 m long.

## 1.2 BRANZ Appraisal

The Ulltraclad® Cavity System has been appraised by BRANZ. Refer to Appraisal Certificate No. 487 (2006).

## 1.3 Ulltraclad® Weatherboards

Ulltraclad® aluminium weatherboards and accessories are extruded by Ullrich Aluminium Co Ltd using 6060 T5 grade aluminium alloy.

Ulltraclad® is available finished in a series of Dulux Durraloy standard powder coat colours. The powder coating carries a 25 year warranty. Other non-standard colours as well as anti-graffiti finishes are also available on request.

## 1.4 Accessories

Accessories supplied by Ullrich Aluminium Co Ltd for use with the Ulltraclad® Cavity System include:

- Cavity vent strip – a folded aluminium profile punched with 5 mm square holes in the bottom face to provide ventilation for the wall cavity and prevent the ingress of vermin. The cavity vent strip is available in 2.4 m lengths.
- Starter strip – an extruded aluminium profile used to locate and secure the bottom of the first course of weatherboards. The starter strip is powder coated and is available in 5 m lengths.

- External and internal corner moulding – extruded aluminium 90° two-piece internal corner mould and 90° two-piece external corner mould. The mouldings are powder coated and are available in 5 m lengths.
- Board jointer – extruded aluminium ‘H’ jointer for jointing lengths of Ulltraclad® weatherboard. The jointer is powder coated and is available in 5 m lengths.
- Board locator – an extruded aluminium locator used to locate the bottom edge and secure the top edge of individual weatherboard courses. The board locators are 50 mm long and are predrilled for fixing.
- Head and jamb flashings – extruded aluminium to suit the window or door trim opening. The flashings are powder coated and are available in 5 m lengths.
- Inter-storey joint flashing – extruded aluminium. The flashing is powder coated and is available in 5 m lengths.
- Ulltraclad® weatherboard fixings – 50 x 3.3 mm AISI-302Cu stainless steel screws.

## 1.5 Handling and storage

Ulltraclad® weatherboards and accessories must be stacked flat, off the ground and supported on a level platform. They must be kept dry either by storing under cover or providing waterproof covers to the stack. Care must be taken to avoid damage to powder coated surfaces. Weatherboards must always be carried on edge.

Cavity battens and other accessories must be stored so they are kept clean, dry and undamaged.

## 2.0 Design information

### 2.1 Design responsibility

The Specifier for the project must ensure that the details provided by Ullrich Aluminium Co Ltd are suitable for the intended application and that additional detailing is provided for specific design or any areas that fall outside the scope and specifications of this literature.

### 2.2 Scope

This literature covers the use of the Ulltraclad® Cavity System using Standard, Baby Corro, Tee Board and Vertical Plank weatherboards as an external wall cladding for buildings within the following scope:

- the scope limitations of NZBC Acceptable Solution E2/ AS1, Paragraph 1.1; and,
- constructed with timber framing complying with the NZBC; and,
- with a risk score of 0-20, calculated in accordance with NZBC Acceptable Solution E2/ AS1, Table 2; and,
- situated in NZS 3604 Building Wind Zones up to, and including 'Very High'.

Standard, Baby Corro, Tee Board and Vertical Plank weatherboards must only be installed horizontally on vertical, flat surfaces.

The Ulltraclad® Cavity System is designed for use with aluminium window and door joinery that is installed with vertical jambs and horizontal heads and sills. *(The Ulltraclad® Cavity System relies on the joinery meeting the requirements of NZS 4211 for the relevant Building Wind Zone.)*

For applications which are outside the scope of this literature and details which are not provided by Ullrich Aluminium Co Ltd, the specifier must ensure that the design meets the relevant performance requirements of the NZBC.

Ullrich Aluminium Co Ltd recommends that professional design advice is sought in these circumstances.

### 2.3 Building regulations

The Ulltraclad® Cavity System if designed, used and installed in accordance with the statements and conditions of this literature and the supporting BRANZ Appraisal, will meet the following provisions of the New Zealand Building Code:

- Clause B1 Structure
- Clause B2 Durability
- Clause E2 External Moisture

## 2.4 Ground clearances

The finished floor level must have a minimum clearance to paved or unprotected ground as required by NZS 3604:1999.

Ulltraclad® Aluminium Weatherboards must overhang the bottom plate on a concrete slab by a minimum of 50 mm as required by NZBC Acceptable Solution E2/AS1, Table 18.

The bottom edge of the Ulltraclad® Cavity System must finish a minimum of 100 mm above paved surfaces or 175 mm above unprotected ground.

At deck or low pitch roof/wall junctions, the bottom edge of the Ulltraclad® weatherboards must be kept clear of any adjacent surface, or above the top surface of any adjacent roof flashing by a minimum of 35 mm.

## 2.5 Structure & framing

Timber wall framing behind the Ulltraclad® Cavity System must be treated as required by NZS 3602:2003 *Timber and wood-based products for use in building*.

Timber framing must comply with NZS 3604 for buildings or parts of buildings within the scope limitations of NZS 3604. Buildings or parts of buildings outside the scope of NZS 3604 must be to a specific design in accordance with NZS 3603 and NZS 4203. Where specific design is required, the framing must be of at least equivalent stiffness to the framing provisions of NZS 3604. Use of timber framing must be in accordance with framing manufacturer's specifications.

In all cases studs must be at maximum 600 mm centres, with dwangs fitted flush between the studs at maximum 800 mm centres.

Cavity battens shall be minimum 45 mm wide x 18 mm thick timber, treated to Hazard Class H3.1.

## 2.6 Special framing requirements

The following are special framing requirements:

- double studs at internal corners;
- extra packers may be required at external corners;
- extra studs (and cavity battens) for Ulltraclad® vertical jointers.

## 2.7 Framing tolerances

In order to achieve an acceptable wall finish, it is imperative that framing is straight and true. Framing tolerances must comply with the requirements of NZS 3604:1999.

## 2.8 Cavity vent strip

The Ulltraclad® Cavity System incorporates an aluminium vent strip to close off the bottom of the cavity and provide resistance against the penetration of vermin. The vermin strip is punched with 5 mm square holes and provides a minimum ventilation opening area of 1000 mm<sup>2</sup> per lineal metre of wall in accordance with the requirements of NZBC Acceptable Solution E2/AS1.

## 2.9 Building wrap

The Ulltraclad® Cavity System must be installed over building paper or wrap complying with NZBC Acceptable Solution E2/AS1, Table 23, or other BRANZ Appraised breather-type membranes. *Note: There is no requirement for the building wrap to be absorbent as it is installed at the back of the cavity and is not in direct contact with the Ulltraclad® weatherboard.*

Unlined gables and walls must incorporate a rigid sheathing or an air barrier fixed to the framing, which meets the requirements of NZBC Acceptable Solution E2/AS1, Table 23. Where rigid sheathings are used, the fixing length must be increased by a minimum of the thickness of the sheathing.

## 2.10 Separation of Cavity Battens and Ulltraclad® Weatherboards

Strips of roof underlay must be fixed to the face of the cavity battens prior to the installation of the Ulltraclad® weatherboards and accessories. The underlay must be cut to the same width as the cavity batten and is required to provide separation between the treated timber and aluminium.

## 2.11 Inter-storey junctions

Inter-storey drained joints must be provided for walls over two storeys in height in accordance with the requirements of NZBC Acceptable Solution E2/AS1, Paragraph 9.1.9.4(b).

# Installation information 3.0

## 3.1 Tools required

The following tools should cover most situations:

- chalk line
- spirit level
- hammer
- battery drill with posi-drive bit
- tin snips
- hack saw
- circular saw or hand saw
- small circular saw with an aluminium cutting blade
- jigsaw
- mastic gun
- 'No More Nails' or similar
- sealant.

## 3.2 Installation sequence

Prior to installation of the window and door joinery:

- building wrap to exterior walls and flexible flashing tape system to window and door joinery openings.
- cavity vent strip.
- cavity battens.
- inner section of internal or external corner flashings.
- vertical board jointer (if wall longer than 6.0 m).
- wall starter between internal or external corner flashings or vertical board jointer.
- inner soffit clip (if being used).
- corner soakers at window openings.
- Ulltraclad® weatherboards up to the bottom of the windows.
- Ulltraclad® jamb flashing.
- Ulltraclad® weatherboards up to the top of the windows and doors.



Following installation of window and door joinery:

- Aluminium head flashing.
- Ulltraclad® head flashing.
- Remaining Ulltraclad® weatherboards.
- Outer soffit clip (if being used).
- Outer section of internal and external corner flashings.

### 3.3 System installation

This section of the literature should be read in conjunction with the installation details. For each section of wall to be clad, repeat the following steps.

The selected building wrap and flexible sill and jamb tape system must be installed in accordance with the manufacturer's instructions prior to the installation of the cavity battens. The building wrap must be installed horizontally and be continuous around corners. Wrap must be lapped 75 mm minimum at horizontal joints and 150 mm minimum over studs at vertical joints. Particular attention must be paid to the installation of the building wrap and sill and jamb tapes around window and door openings to ensure a continuous seal is achieved and all exposed timber wall framing in the opening is protected. All penetrations through the building wrap must be sealed and joints sealed or lapped 150 mm.

The Ulltraclad® Cavity Vent Strip is installed with the bottom of the vent strip flush with the underside of the bottom plate (or flush with the underside of the cavity battens).

*Note: A minimum 15 mm drip edge to the bottom of the Ulltraclad® weatherboard must be maintained at all times.*

Cavity battens must be installed over the building wrap to the wall framing at maximum 600 mm centres where the studs are at maximum 600 mm centres or at 400 mm centres where the studs are at 400 mm centres. The battens must be fixed in place with 40 x 2.5 mm hot-dipped galvanised flat head nails at maximum 800 mm centres. Strips of roof underlay must be stapled to the face of the battens after they have been installed. Refer to Paragraph 2.8.

When the cavity battens are installed at greater than 450 mm centres, the building wrap must be supported between the battens to prevent the wrap bulging into the cavity space when bulk insulation is installed in the wall frame cavity. Acceptable means of support include polypropylene strap, galvanised wire mesh or additional cavity battens.

At the bottom corner of window openings, fix 100 mm long aluminium soakers flush with the top of the sill trimmer. The soaker must be folded to divert incidental water that may enter the system at this point through the window joinery to the back of the cladding. Refer to Detail 6 for further guidance.

To start installation of the weatherboard system, use a chalk line to set a reference line on the cavity battens 45 mm up from the underside of the bottom plate, making sure the line is level and continuous around the building. This line will be used for the installation of the wall starter which will overhang the underside of the bottom plate by 45 mm.

If there is more than one starting level on the building, work from the lowest point up to the next level and try to get the joint in the boards to coincide with the higher starter. Some adjustment of the starter positions may be required to achieve this.

Measure the height from the underside of the bottom plate to the underside of the soffit. Cut the inner section of the internal or external corner flashing (depending on building layout) and fix through the cavity battens with 30 x 2.5 mm hot-dipped galvanised clouts. If the wall to be clad is longer than 6.0 m, cut a vertical board jointer to the height of the wall plus 50 mm and fix to the wall framing at the selected location with 30 x 2.5 mm hot-dipped galvanised clouts, ensuring the jointer is plumb.

If the wall has a door opening in it, cut a section of jamb flashing to the height of the joinery unit and fix through the cavity battens with 30 x 2.5 mm hot-dipped galvanised clouts.

Measure between the flashings and cut the wall starter 40 mm less than this measurement. Fix the starter to the bottom plate using the reference line as the set-out point for the top of the starter. Leave a 20 mm gap between the wall starter and the flashing at each end. This gap is important as it acts as a drain point for any moisture that may enter the wall.

At the top of the wall, fix the inner soffit clip through the cavity battens with 30 x 2.5 mm hot-dipped galvanised clouts.

Measure between the flashings and cut the first weatherboard to this dimension less 8 mm. Fit the weatherboard over the wall starter so it securely clips in place. Leave a 4 mm gap at each end and secure the top of the weatherboard to each stud at maximum 600 mm centres with locator clips fixed with 50 x 3.3 mm stainless steel screws (Ulltraclad® screws). At the centre of the board (approximately), put a bead of 'No More Nails' adhesive on the bottom of the locator clip before fitting it to the board. This acts as a hold for expansion. Carry on installing the weatherboards up to the underside of a window opening, securely locating the bottom of each board over the locator clip and fixing the top of the board to each stud as detailed. If a section of the weatherboard overhangs the window opening, cut away this section of board and fix the weatherboard in place. *Note: Do not install a locator clip at the window opening at this stage.*

Measure from 20 mm below the line of the opening to the top of the window frame and cut a jamb flashing to that length. Cut out the side of the jamb flashing so it sits over the board. Bend the bottom of the back face of the jamb flashing forward to divert any moisture into the back of the weatherboard. Refer to Detail 6. Repeat for both sides of the window. Once the jamb flashing has been installed, the weatherboard locator clip can be installed.

Complete the weatherboard installation up to the top of the window or door opening following instructions previously given.

The aluminium window and door joinery and associated head flashings must be installed in accordance with the joinery manufacturer's instructions. A 7.5 - 10 mm nominal gap must be left between the joinery reveal and the wall framing so a PEF rod and air seal can be installed in accordance with NZBC Acceptable Solution E2/AS1, Paragraph 9.1.6 after the joinery has been secured in place.

At the top of the window or door, measure and cut a length of aluminium head flashing 40 mm longer than the face dimension of the window or door frame. Cut the head flashing around the cavity batten and jamb flashing and install with the flashing upstand hard against the building wrap. Cover the flashing upstand with a second layer of building wrap or proprietary flashing tape. Seal the junction between the head flashing, cavity batten and jamb flashing. Refer to Detail 15 for further guidance.

After installation of the Ulltraclad® Cavity Vent Strip above the aluminium head flashing, cut a length of Ulltraclad® head flashing 160 mm longer than the width of the window or door frame. Cut the bottom of the channel in 70 mm from both sides. Fold the channel floor down 90° and trim to 20 mm in length. Install the head flashing with the fold fitting into the jamb flashing channel, ensuring a 5 mm gap is maintained between the two head flashings. Refer to Details 12 and 15.

Cut the next weatherboard to fit inside the head flashing channel. Apply a continuous bead of sealant along the cut edge and fit the board in place. Install the remaining weatherboards to complete the installation.

Once all weatherboards have been installed, cut the outer section of the internal and external corner flashings to allow a 50 mm overhang past the bottom plate, and secure in place. Measure and cut the outer soffit clip to finish tight between the internal and external corner flashings and secure in place.

### 3.4 Variations to Installation Methods for Vertical Plank Weatherboards

To start installation of the Vertical Plank weatherboard system, use a chalk line to set a reference line on the cavity battens making sure the line is level and continuous around the building. This line will be used for the installation of the Vertical Plank wall starter and must be positioned to ensure that the overhang for the starter channel to the underside of the bottom plate is 50 mm minimum. 3 mm diameter holes must be drilled in the bottom of the starter channel at 600 mm centres to allow any trapped water to drain.

The first row of Vertical Plank weatherboards are half height boards and are installed with the bottom of the weatherboard inserted into the starter channel. Prior to installation of the Vertical Plank, and once the weatherboards have been cut to length, the top and middle stiffener and upstand on the back face of the board must be removed for a length of 30 mm from each end. The upstand on the bottom stiffener must also be removed for a length of 30 mm from each end. Refer to Detail 2.

Once the first course of Vertical Plank has been inserted into the starter channel, the top of the board shall be fixed through the board upstand, through the cavity battens to the stud. Subsequent courses of Vertical Plank shall be installed by inserting the ball section of the board into the socket of the previous board, and must be secured at the top by fixing through the board upstand, through the cavity battens to the studs at maximum 600 mm centres.

All other installation details must be followed as for Standard, Baby Corro and Tee Board weatherboards.

### 3.5 Cutting Ulltraclad® Aluminium Weatherboards

When cutting Ulltraclad® Aluminium Weatherboards with a circular saw, apply a strip of masking tape to each side of the cut to prevent the paint surface from being damaged.

## 4.0 Maintenance

Building owners are responsible for the maintenance of the Ulltraclad® Cavity System. Annual inspections must be made to ensure that all aspects of the cladding system, including flashings remain in a weatherproof condition. Any damaged areas or areas showing signs of deterioration which would allow water ingress, must be repaired immediately. Sealant and the like must be repaired in accordance with the sealant manufacturer's instructions.

Regular cleaning (at least 6 monthly) of the powder coating with water and a mild detergent is required to remove grime, dirt and organic growth, to maximise the life and appearance of the cladding. When cleaning powder coated surfaces, proceed as follows:

1. Carefully remove any loose deposits with a wet sponge.
2. Use a soft, non-abrasive brush and a mild detergent solution to remove dirt, salt and other deposits.
3. Rinse off with clean water.

# Health and safety

5.0

Hearing and eye protection must be worn while cutting Ulltraclad® Aluminium Weatherboard and accessories.



# ULLRICH ALUMINIUM SALES CENTRES

## WHANGAREI

2 Gumdigger Place  
PO Box 1694 Whangarei  
Tel 09 438 7380  
Fax 09 438 4587  
Email: Whgrsls@uacl.co.nz

## ROTORUA

124 Riri Street  
PO Box 965 Rotorua  
Tel 07 346 8213  
Fax 07 346 8215  
Email: Rotsls@uacl.co.nz

## WELLINGTON

1 Cornish St Petone  
Private Bag Te Puni MC  
Tel 04 568 8188  
Fax 04 569 8759  
Email: Wgtnsls@uacl.co.nz

## SILVERDALE

24 Anvil Road Silverdale  
Hibiscus Coast  
Tel 09 427 0017  
Fax 09 427 0030  
Email: Silvsales@uacl.co.nz

## NAPIER

Cnr Niven & Edmundsen Sts  
PO Box 695 Napier  
Tel 06 843 3114  
Fax 06 843 3185  
Email: Napsls@uacl.co.nz

## NELSON

6a Forests Road  
PO Box 2233 Stoke  
Tel 03 547 4103  
Fax 03 547 8343  
Email: Nelsales@uacl.co.nz

## AUCKLAND WEST

43 The Concourse  
Henderson  
Tel 09 836 6061  
Fax 09 835 1365  
Email: Hendsls@uacl.co.nz

## AUCKLAND CENTRAL

33 Great South Road  
PO Box 222 44 Otahuhu  
Tel 09 276 3789  
Fax 09 276 3342  
Email: alkalum@uacl.co.nz

## AUCKLAND SOUTH

118 Wiri Station Road  
PO Box 98 843 SAMC  
Manukau City  
Tel 09 262 6262  
Fax 09 262 6266  
Email: alkalum@uacl.co.nz



## CHRISTCHURCH

4 Iversen Terrace  
PO Box 100 50 Christchurch  
Tel 03 366 7939  
Fax 03 379 5910  
Email: Chchsls@uacl.co.nz

## TIMARU

115 Hilton Highway  
PO Box 2126 Washdyke  
Tel 03 688 7649  
Fax 03 688 7659  
Email: Timrsls@uacl.co.nz

## DUNEDIN

391 Kaikorai Valley Road  
PO Box 5010 Dunedin  
Tel 03 453 0679  
Fax 03 453 5958  
Email: Dunsls@uacl.co.nz

## TAURANGA

17 McDonald Street  
PO Box 4492 Mt Manganui  
Tel 07 575 3499  
Fax 07 575 0218  
Email: Taurgsls@uacl.co.nz

## NEW PLYMOUTH

217 Courteney Street  
PO Box 8023 New Plymouth  
Tel 06 759 9120  
Fax 06 759 1598  
Email: NPlythsls@uacl.co.nz

## INVERCARGILL

25 Bond Street  
PO Box 1681 Invercargill  
Tel 03 218 4124  
Fax 03 218 4024  
Email: Invsls@uacl.co.nz

## HAMILTON

Pukete Industrial Estate  
Maui St PO Box 1138  
Tel 07 849 2909  
Fax 07 849 2589  
Email: Hamsls@uacl.co.nz

## PALMERSTON NORTH

8 Railway Road  
PO Box 4054 Palmerston North  
Tel 06 356 2007  
Fax 06 356 8539  
Email: PNthsls@uacl.co.nz

## EXPORT DIVISION

118 Wiri Station Road  
PO Box 98 843 Manukau City  
Tel 09 262 6262  
Fax 09 262 6267  
Email: exports@uacl.co.nz

Represented throughout Australia by Ullrich Metals Pty Ltd  
PO Box 2182 Smithfield NSW 2164  
185-187 Woodpark Rd Smithfield Tel 02 9725 2377 Fax 02 9725 2400

Representative and franchised operations throughout the South Pacific

## ULLRICH ALUMINIUM CO LTD

PO Box 98 843 SAMC Manukau City  
New Zealand Email: alkalum@uacl.co.nz  
Tel 09 262 6262 Fax 09 262 6265  
www.ullrich-aluminium.co.nz

