Absorbent Breather type
building underlay
dressed into opening with
flexible tape installed over
underlay to corners at head

Flexible flashing tape
over flashing to full
width of opening

2 part head flashing with
15degree fall. End of head
flashing requires folded
stop end or application
of sealant as stop end

50mm long sealant strip
at both ends of flashing

Flashing tape over
building wrap fitted
around corners

Palliside Rusticated
weatherboard fixed with Palliside
fastfix fasteners @500crs

Additonal building
underlay from
overlap above, lapped
over flashing.

Palliside 2 part jamb
flashing base

Studs

Note:
Window omitted
for clarity.

Scale:	1:5
Date:	March 2015
Detail No:	**DF-40-R**

PALLISIDE

the smart choice in weatherboards

Window Head Layout

Palliside Rusticated Weatherboard