

Resene Summit Roof

waterborne roof paint

Resene Summit Roof is a unique waterborne satin for ease of application and maximum life over well weathered COLORSTEEL®, COLORBOND®, properly prepared metal surfaces and cementitious surfaces.

exterior

Typical uses

Direct to:

- Properly prepared cementitious surfaces
- Properly prepared metals (aluminium, galvanised iron, mild steel or Zinalume)
- Well weathered COLORBOND® or COLORSTEEL®

Physical properties

Vehicle type	Acrylic emulsion with special pigment binding properties
Pigmentation	Titanium dioxide (and/or other colour pigments), calcium carbonate, talc
Solvent	Water
Finish	Satin
Colour	Selected Resene Total Colour System.
Dry time (minimum)	45 minutes at 18°C
Recoat time (minimum)	3 hours
Primer required	Direct to substrate on some surfaces. Depends on substrate, degree of weathering, etc.
Theoretical coverage	12 sq. metres per litre
Dry film thickness	32 microns at 12 sq. metres per litre
Usual no. of coats	2; some colours may require an additional coat
Abrasion resistance	Good
Chemical resistance	Good
Heat resistance	Good
Solvent resistance	Good
Toxicity	Suitable for the collection of drinking water
Durability	Excellent
Thinning and clean up	Water
VOC	c. 60 grams per litre (see Resene VOC Summary)

Performance

Performance and limitations

1. Good corrosion resistance over metals.
2. Direct to substrate on some surfaces.
3. Excellent adhesion to Resene primers - refer schedule overleaf.
4. Acid and alkali resistant - inhibits mould growth.
5. An Environmental Choice approved product.

Limitations

1. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
2. New unweathered COLORSTEEL® or COLORBOND® must either be lightly sanded, or allowed to undergo direct weathering for a minimum period of one month before application of Resene Summit Roof.
3. Not normally used on opening sashes and doors (use Resene Enamacryl - see [Data Sheet D309](#)).
4. Disconnect roof downpipes until after the first shower of rain in order to flush away surplus non-toxic wetting agents before the surface is used for the collection of drinking water.
5. Light colours are recommended for UPVC surfaces as dark shades will cause warping.
6. Not suitable for roof areas where water ponding occurs.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of product. If in doubt contact Resene.



Summit Roof waterborne roof paint

Surface preparation

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease, mould and release agents. If moss and mould are present, treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)). Waterblasting at 21,000 kps (3000 psi) is the best surface preparation method prior to painting weathered cementitious surfaces or galvanised steel.

When painting new or old galvanised roofs, ensure surface to be painted is thoroughly cleaned using Resene Roof Wash and Paint Cleaner (see [Data Sheet D88](#)). Flush clean with freshwater. Consult Resene for technical advice on painting of old cementitious roof tiles.

Resene Summit Roof may be applied directly over the following substrates: new previously uncoated galvanised iron, new aluminium, new previously uncoated Zinalume or sound cementitious surfaces. For best protection, prime galvanised steel or Zinalume first. New unweathered COLORSTEEL® or COLORBOND® must either be lightly sanded, or allowed to undergo direct weathering for a minimum period of one month before application of Resene Summit Roof.

Prime old unpainted fibre cement or plaster with Resene Sureseal (see [Data Sheet D42](#)).

Prime uncoated weathered galvanised steel or Zinalume with Resene Galvo One (see [Data Sheet D41](#)).

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Prepare as per schedule above. Apply two coats of Resene Summit Roof by brush, speed brush, synthetic fibre roller or spray. For best protection use a three coat system – either a primer and two topcoats or three topcoats.

Precautions

1. Ensure correct primer and/or sealer is used where required.
2. Fill all nailholes after priming.

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 785, Ashmore City, Queensland 4214
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz