



Palliside Traditional Bevel Back weatherboard fixed with Palliside nails

Additional breather type building underlay from overlap above, lapped over flashing.

Cavity base closure

H3.1 timber packer to suit

Palliside fastfix fastener

35mm min
15mm min drip

4mm gap

7.5mm

10mm min

Head flashing with 15 degree fall. End of head flashing requires stop end achieved by way of upturning head flashing or application of sealant at cavity batten junction

Sealant between head flashing and window flange in very high wind zone and above

Breather type building underlay dressed into opening with flexible tape installed over underlay to corners at head

H3.1 timber (or equivalent) packer to suit

Airseal over PEF rod