



- The panel vertical joint must be formed on the batten fixed over the stud.
- If studs are placed at 400mm centres no intermediate support is required.

