



Notes:

- Ensure that a continuous 6mm bead of adhesive sealant is applied between CLD[®] Structural Cavity Batten and Titan[®] Facade Panel.
- Ensure that the required edge distance is maintained when fixing.
- Seal cut edges with a primer compatible with final coatings.
- Refer to Table 3 for Titan[®] Facade Panel fixing options.
- Push panel hard against CLD[®] Structural Cavity Batten.