



**Step 1**

- Check Architect's plans for the type of flashing to be used.

**Step 2**

- Check fixing centres and edge distances.
- If top fixings are to be hidden by the Z flashing they will need to be fixed and sealed before the Z flashing is installed.
- Cut edges need to be primed with sealer.

**Step 3**

- When 50 year durability is required refer Table 20 E2/AS1.

**Step 4**

- The flashing to be placed in the centre of the floor joists. Do not fix CLD® Structural Cavity Battens or panels into floor joists.