



Absorbent Breather type building underlay dressed into opening with flexible tape installed over underlay to corners at head

Flexible flashing tape over flashing to full width of opening

2 part head flashing with 15degree fall. End of head flashing requires folded stop end or application of sealant as stop end

50mm long sealant strip at both ends of flashing

Flashing tape over building wrap fitted around corners

Palliside Traditional Bevel Back weatherboard fixed with Palliside fastfix fasteners @500crs

Additional building underlay from overlap above, lapped over flashing.

Palliside 2 part jamb flashing base

Studs

Note:
Window omitted for clarity.