



Step 1

- Check Architect's specification to confirm the type of horizontal joint required.

Step 2

- Check fixing centres and edge distances.
- Cut edges need to be primed on site.

Step 3

- Flash the horizontal gap between battens with batten flashing and seal as shown.
- Aluminium 'T' socket to be cut flush to the vertical edges of panels and should start below the batten flashing.

Step 4

- Do not fix panels or battens into floor joists.
- For edge distance of fixings refer to Section 6.