



NOTES:

- ALL DIMENSIONS ARE NOMINAL AND MAY VARY WITH MATERIAL

- *THE OVERFLOW SHOULD HAVE ADEQUATE CAPACITY. THE OVERFLOW OF THE GUTTER NEEDS TO BE CONSIDERED WHEN DESIGNING AND INSTALLING THE METALCRAFT ROOFING GUTTER*