



## Notes:

- Check panel extends past bottom plate as specified in Architects specification (50mm min).
- uPVC Vent strip must remain level and secure during construction. Cut and fix uPVC vent strip between CLD<sup>®</sup> Structural Cavity Battens fixed under the panel joints.
- Check vent strip is free from site debris.
- Refer to Table 3 for Titan<sup>®</sup> Facade Panel fixing options.
- Push panel hard against CLD<sup>®</sup> Structural Cavity Batten.