


Window Profile view: Head B


CAVITY FIX



In very high and extra high wind zones, sealant must be installed between underside of head flashing and top edge of window head flange. — see E2/AS1 Fig. 71(c)

Window Profile View: Sill B


CAVITY FIX



* Alternative solution is the Smartclad 88x34 or 42x34 facing boards which require no pre-cut scriber.

Window Front view: Head B

CAVITY FIX



Window Front view: Sill B

CAVITY FIX

