

INSTALLATION




We strongly recommend this light fitting is installed by a registered electrician. This guide can be used to install both models listed in this manual.




Switch off the power supply before commencing any electrical work.




2 Unscrew the fixing cover screws with the allen key supplied and remove the rear mounting base.



3 Use the rear base to mark the position of screw holes onto the mounting surface. Use a spirit level to ensure correct orientation.




4 Drill the wall to depth of about 40mm and fit the wall plugs (supplied). Care should be taken to avoid drilling or screwing into concealed electrical wiring/plumbing.




Push the power supply through the cable gland.

Affix the rear base to the mounting surface with mounting wall screws supplied. To maintain the IP rating, a round 3 core 0.75mm² (min) cable should be used.




6 Connect the power cables to the terminal block securely using the wiring diagram in Step 7.



7 Terminate the power supply cable.



8 Reattach and screw securely the cover to the base.
Ensure cables are not pinched when closing the unit.



9 Reconnect mains power and test circuit.