

**JURALCO EDGETEC® MINI POST**BALUSTRADE and POOL FENCING SYSTEMS

# Juralco Edgetec® Mini Post Balustrade System

Juralco Aluminium Building Products Ltd designs and distributes specialist aluminium joinery systems through a national network of franchised fabricators and agents.

For more than 25 years we have been at the forefront of specialist aluminium door and window products suitable for New Zealand joinery and building methods. Our comprehensive product range includes security and insect screens, balustrades and gates, shutters and awnings, shower screens, wardrobe doors and organisers and internal doors.

The Juralco Mini Post Balustrade System has 3 x Mounting options, Top, Face and Gutter Bracket and is designed to use12mm Frameless Toughened Glass.

The system is extremely versatile and can be custom made in a range of configurations and powder-coat colours to meet most modern architectural requirements.



Juralco Edgetec Mini Post Framless Balustrade Face Fix to Timber Deck



Juralco Edgetec Mini Post Framless Balustrade Top Fix to Tiled Concrete Deck. Pool



Juralco Edgetec Mini Post showing the Interlinking Top Rail and the use of a Top Mounted Edge Post and Brackets back to the structure



Juralco Edgetec Mini Post Framless Balustrade Face Fix to Timber Deck

All pages © Copyright Juralco Aluminium Building Products Ltd, 2024



# Juralco Edgetec® Mini Post Balustrade System

Complies With AS/NZS 1170:2002, NZS 4223.3.2016, NZ Building Code B1, B2, F2, F4 and F9

# Mini Post Balustrade is for Domestic and Residential Occupancy types A, A Other and C3 only Occupancy Types as per AS/NZ 1170.1.2002. Not suitable for Commercial C3 applications

Code	Type of Occupancy for part of the building or structure	Specific Uses	Glass
А	Domestic and Residential activities	All areas within or serving exclusively one dwelling including stairs, landings etc, but excluding external balconies and edges of roofs.	12mm Toughened Glass,
A Other, C3	Areas without obstacles for moving people and not susceptible to over crowding	Stairs, landings, external balconies, edges of roofs etc.	13.52mm SentryGlas

Note 1	All for 12mm Toughened Glass and 13.52mm SentryGlas, Frameless. Glass must have a minimum strength of 100mpa. All edges polished
Note 2	Juralco Balustrade Systems building code compliance documentation requires all balustrade installations are to be completed in accordance with the requirements of our authorised installer certification.
Note 3	All Frameless Glass balustrades using Toughened Glass must have an Interlinking Rail to conform to NZS 4223.3.2016. Not necessary for Swimming Pool Fencing
Note 4	Juralco Edgetec® Mini Post Balustrade Patent Application #NZ603315

Note 4 Juralco Edgetec® Mini Post Balustrade Patent Application #NZ603315

masterspec partner
Section 4852JB

# Index

Heading	Pages	Description. Use the Bookmarks  List to jump to selected pages			
Specifications	4	Juralco standard specification sheet and Powder coating recommendations			
	5 - 6	Shows typical Balustrade layouts different Mount and Glass Types			
Configurations	7	Shows typical Stair Layouts and attach details			
	8	Shows typical Pool Access Stairs and a Step			
Glass Pool Gate	9	Shows Glass to Glass Pool Gate for 12mm Toughened Glass			
General	10 - 12	Shows the Mini Post cross sections and all details			
Components	13 - 14	Shows all Components			
	15 - 16	Shows Approved Timber Construction and Mounts			
Mountings	17 - 24	Shows TOP Mounting details - to Timber (p17-18), Steel (p19-20) and Concrete (p21-24)			
Mountings	25 - 30	Shows FACE Mounting details - to Timber (p25-27), Steel (p28-29) and Concrete (p30)			
	31 - 35	Shows GUTTER BRKT Mounting details - to Timber (p31-32), Steel (p33-34) and Concrete (p35)			
Glass Panels.	36- 43	Shows all Interlinking Rail options (5 x Total). Swivel connectors and End connections			
Top edge. Safety	44	Shows Glass stiffener brackets, Fixed and Adjustable angles			
End Brackets	45 - 48	Shows Interlinking Rail End bracket attachments to Posts and Structures			
Rail mounted to Glass Panel	49	Shows Interlinking Rail Side mounted to a Glass Panel and all End brackets			
Joiners and End Plates	50 - 51	Shows Interlinking and Handrail Joiners and End Plates			
Surface Care	52 - 54	Instructions for the care of Glass, Powder Coated and Stainless Steel surfaces			

# Juralco Edgetec® Mini Post Balustrade System Specifications, Powder Coating

# Juralco Aluminium Building Products Ltd (JABP) Specifications for Juralco Edgetec® Mini Post Balustrade System

#### 1.Scope

- This specification details the documents the Juralco Mini Post Balustrade System refers to in relation to the New Zealand Building Code, the manufacturer's documents, products used in the System, requirements in relation to fixing and surface finishing.

#### 2. NZBC Compliance

- The Juralco Mini Post Balustrade System has been reviewed by Lautrec Technology Group Ltd, Engineers to demonstrate compliance with the structural requirements of the New Zealand Building Code and AS/NZS1170: 2002 occupancy A, A Other and C3, NZS 3604 for Low, Medium, High, Very High and Extra High Wind Zones
- The Structural Engineering design includes the requirements of B1 Structure, B2 Durability, F2 Hazardous material and F4 Safety from falling, all from the Building Code.
- Verification Method B1 / VM1, B2/AS1, F4 / AS1
- All glass used in the Juralco Mini Post Balustrade System must conform to AS/NZS2208.
- Complies with NZS4223.3.2016
- Separation of dissimilar materials (as relates to B2 compliance) have been reviewed.
   For other combinations refer to NZS3604:2011 Section 2.3.3 Separation and Section 4 Durability

#### 3. Manufacturer's Documents

- The Juralco Mini Post Balustrade System manual details all extrusions and components used for the fabrication and installation/fixing of the system.
- A Producer Statement 1(Design) is available.

Copies of the above documents are available from:

Juralco Aluminium Building Products Ltd

48 Bruce McLaren Rd, Henderson, Auckland

Phone 09 478 8018 Fax 09 478 7883 Email specify@juralco.co.nz

- Any deviation from the standard fabrication or installation/fixing must be accompanied by a site specific PS1 with site specific calculations and drawings

#### 4 Products

- Only extrusions, components and hardware supplied by or specified by JABP may be used in the Juralco Mini Post System
- Aluminium extrusions, components and hardware unless specified are manufactured to 6060 T5 specifications
- Stainless Steel components, hardware, fixings all components to 316 grade
- Glass all glass used in the Juralco Mini Post Balustrade System must conform to the specifications as listed in the Juralco Mini Post manual with each panel conforming to AS/NZS 2208 as confirmed by the Safety Stamp detailing the manufacturer's description and licence number.

#### 5. Surface Finishing

- Juralco Aluminium Building Products Ltd is a Dulux Registered Applicator site, registration number 2101.
   JABP uses only Dulux branded powder coating materials
- Dulux Duralloy® powder coating systems are suitable for properties greater than 100m from high tide level AAMA 2603 performance. Residential buildings, 3 levels max. Warranty 10 yrs
- Dulux Duralloy Plus® powder coating systems are suitable for properties greater than 10m from high tide level.
   AAMA 2603 performance. Residential and Light commercial buildings, 3 levels max Warranty 15 yrs
- Dulux Duratec® powder coating systems are suitable for properties greater than 10m from high tide level AAMA2603 and 2604 performance. All Residential and Commercial buildings. Warranty 25 yrs

# 6. Installation and Fixing

- The Juralco Mini Post Balustrade System must only be installed in accordance with the Juralco Mini Post Balustrade System manual
- Any deviation from that specified in the Juralco Mini Post manual must only be in accordance with the site specific PS1 with site specific calculations and drawings listing the non standard details
- The Juralco Mini Post Balustrade System must only be fabricated/installed by a Juralco approved fabricator
- Upon completion of the installation the fabricator must supply the owner with a PS3 (Construction)

#### Important information - Powder Coating systems.

<u>Powdercoat Systems</u> The new standard Dulux powder coating system used by Juralco is Duralloy Plus<sup>®</sup>. Also Duralloy<sup>®</sup> and Duratec<sup>®</sup>. All as per specs above. Juralco Powder coated prices are for Duralloy Plus<sup>®</sup> and Duralloy<sup>®</sup> (same pricing). Duratec<sup>®</sup> prices on application.

Attachment to structures A PVC Tape or similar material spacer must be used to separate powder coated aluminium items from all concrete and steel structures. Failure to do so can lead to the chemicals in the structure affecting the powder coating, leading to corrosion.

<u>Swimming Pools</u> The chlorinated water in swimming pools can cause the deterioration of powder coated surfaces, leading to corrosion of the underlying surface. It is recommended that Powder coated surfaces be 1200mm min from a pool.

<u>Care</u> The Dulux powder coating warranty period is conditional upon the surface being maintained in accordance with the Dulux 'Care and Maintenance Instructions'. Download from Dulux or refer to the back page of this manual.



# Juralco Edgetec® Mini Post Balustrade System - Typical Layouts

Mini Post + Interlinking Rail

Glass must have a minimum strength of 100MPa. All edges polished

Residential & Domestic only Occupancy types A, A Other and C3

12mm Toughened Glass

# Top Fix and Face Fix only


- BH max 1200mm Wind Zone - D max 720mm

- OH max 250mm

- BH max 1100mm Very High Wind Zone - D max 720mm - OH max 250mm

- BH max 1000mm Extra High Wind Zone - D max 720mm - OH max 250mm

Exceeds the wind loading for up to and including Wind Zones as detailed above



**Residential & Domestic only** Occupancy types A, A Other and C3

12mm Toughened Glass

# Gutter Brkt Face Fix only

- BH max 1200mm High Wind Zone - D max 720mm - OH max 250mm


- BH max 1100mm Verv High Wind Zone - D max 720mm - OH max 250mm

Extra High - BH max 1000mm

Wind Zone - OH max 720mm - OH max 250mm

Exceeds the wind loading for

up to and including Wind Zones as detailed above




#### MiniPost **Pool Fencing Only** TOP or FACE FIX ONLY

Glass must have a minimum strength of 100MPa. All edges polished

#### 12mm Toughened Glass (Pool Fence only)

Wind Zone	D max	OH max
up to Medium	1000	500
up to High	750	375
up to V High	600	300

Exceeds the wind loading for up to and including Wind Zones as detailed above



Applies to Swimming Pools as of Jan 2017, complies with the Building Code clause F9 and section 162C of the Building Act.

**Applies to Pool Fences not** protecting a fall of 1.0m or more

#JURALCO www.juralco.co.nz ph (09) 478 8018 Juralco Edgetec® Mini Post Balustrade and Pool Fencing Systems

Issue 10-24 v1

Page 5

# Juralco Edgetec® Mini Post Balustrade System - Typical Layouts

Mini Post + Stiffener Brackets

Glass must have a minimum strength of 100MPa. All edges polished

Residential & Domestic only Occupancy types A, A Other and C3


13.52mm SentryGlas

# Top Fix and Face Fix only

Very High - BH max 1200mm Wind Zone - D max 720mm - OH max 250mm

Extra High - BH max 1100mm
- D max 720mm
- OH max 250mm

Exceeds the wind loading for up to and including Wind Zones as detailed above



Residential & Domestic only Occupancy types A, A Other and C3

13.52mm SentryGlas


# **Gutter Brkt Face Fix only**

Very High - BH max 1200mm

Wind Zone - D max 720mm - OH max 250mm


Extra High - BH max 1100mm Wind Zone - D max 720mm - OH max 250mm


Exceeds the wind loading for up to and including Wind Zones as detailed above




**NOT** suitable for Pool fencing


# Juralco Edgetec® Mini Post Balustrade System - Typical Stair Layout





# Juralco Edgetec® Mini Post Balustrade System - Typical Stair Layout leading to a Pool






# Juralco Edgetec® Mini Post Balustrade System Juralco Glass to Glass Hydraulic Hinges and Latches for Pool Gates


#### Glass to Glass SS Hinge 12mm Glass only

Powder Coated - JET/HH180/SCC Polished SS -JET/HH180/PSS




# Glass to Glass Latches


Note: Can be assembled as RH or LH




Clamp Plates 316SS Polished or Satin finishes Latch Non Locking type JET/MGL180/PSS JET/MGL180/SSS



Clamp Plates Aluminium Latch Non Locking type JET/MGL180




Clamp Plates 316 SS Polished or Satin finishes Latch Locking type JET/MGL180L/PSS JET/MGL180L/SSS



Clamp Plates Aluminium Latch Locking type JET/MGL180L

### Latch and Hinge Positions



# Specifications..

Glass Thickness 12mm

Hinge and Latch packers, 1.0mm each side Gate width max = 900mm

Gate Height min =1200mm

Gate Weight max = 65 kg (= 2.1sqm)

Hinge - Auto close. Adjustable Closing Speed and angle. Non Hold open

Latch, Side pull magnetic. Gap = 8mm min -12mm max Gate to open outwards; Latch to be mounted on inside. Installation to conform to NZS8500:2006


Complies with NZBC Clause F9

#### **Closing Speed Adjust**


- Remove the covers
- Slotted screwdriver, turn Screw C
- Clockwise = slower
- Synchronise both hinges for equal speed.

# Angle Adjust

- Remove the covers
- Using a M3 allen key, loosen the two D screws 360deg.
- Adjust the angle (+,- 10 deg max)
- -Tighten both firmly at correct angle



# See Glass Pool Gate Manual for more details and other options




Elevation showing the Main Features For a Top Fix Bracket

#### Notes:

- 1 Clamp panels, 3mm SS and Gasket material . Held in place with JMF/X03 Double sided tape
- 2 Glass Clamping Tighten bottom grubscrew first, then two top screws. Do not over tighten, max torque 5Nm.
- 3 MP Cover Panels. Held in place with JMF/X02 Double sided tape
- 4 Use top grub screw for vertical alignment of the glass panel.
- 5 Ensure that the glass panel is not in contact with any of the Mini post
- 6 For height adjustment pack the bottom of the glass with additional bottom gaskets as required.


# Juralco Edgetec® Mini Post Balustrade System - Face Fix



Elevation showing the Main Features For a Face Fix Bracket

#### Notes:

- $\ensuremath{\text{1}}$  Clamp panels, 3mm SS and Gasket material . Held in place with JMF/X03 Double sided tape
- $\hbox{2-Glass Clamping-Tighten bottom grubscrew first, then two top screws. Do not over tighten, max torque 5Nm.}\\$
- 3 MP Cover Panels. Held in place with JMF/X02 Double sided tape
- 4 Use top grub screw for vertical alignment of the glass panel.
- 5 Ensure that the glass panel is not in contact with any of the Mini post
- 6 For height adjustment pack the bottom of the glass with additional bottom gaskets as required.




### Notes:

- 1 Clamp panels, 3mm SS and Gasket material . Held in place with JMF/X03 Double sided tape
- 2 Glass Clamping Tighten bottom grubscrew first, then two top screws. Do not over tighten, max torque 5Nm.
- 3 MP Cover Panels. Held in place with JMF/X02 Double sided tape
- 4 Use top grub screw for vertical alignment of the glass panel.
- 5 Ensure that the glass panel is not in contact with any of the Mini post
- $\bf 6$  For height adjustment pack the bottom of the glass with additional bottom gaskets as required.

# Juralco Edgetec® Mini Post Balustrade System - Components

# Top Fix Mini Post Part No JET/MP/T


66.6mm deep x 45mm wide x 200mm high, including Baseplate. For 12mm or 13.52mm Glass only



Supplied as a <u>complete Kit</u>, including Screws for base plate. Base plate extra. Powder coat, SCC to your choice

### Base plate Part No JET300


Top Mount



110mm x 90mm x 12mm - 4 x hole

# Face Fix Mini Post Part No JET/MP/F


66.6mm deep x 45mm wide x 400mm high. For 12mm or 13.52mm Glass only



Supplied as a <u>complete Kit</u>. Powder coat, SCC to your choice


#### Base plate Part No JET301

Top Mount. Concrete and Steel



120mm x 90mm x 12mm - 2 x hole


### Gutter Bracket Spacer Part No JEC 139



135mm x 120mm x 5mm thick

#### Base Plate, Hidden Fix Part No JET304


Top Mount. Concrete



100mm x 100mm x 15mm - 4 x fixings 8 x 10dia M10 Blind Threaded holes Installer to cut/install M10 SS Threaded Rod to correct depth. Loctite threaded rod in place

#### Base plate, Hidden Fix Part No JET305


Top Mount Hidden Fix



120mm x 100mm x 15mm - 4 x hole For M10 Countersink screws


#### Gutter Bracket Part No JET137/65

Top/Face Mount



120mm wide x 135mm high - 4 x hole

# Juralco Edgetec® Mini Post Balustrade System - Components




Under Glass

edge


# **Approved Timber Construction Options, fixing into Double Joists**

M10 SS Coachscrews, Bolts or Threaded Rod Refer individual construction pages for further details



1 - Top Fix to Double Joists


# 2 - Face Fix directly to Double Joists



3 - Gutter Bracket Face Fix directly to Double Joists


# **Approved Timber Construction Options, fixing into Double Joists**

M10 SS Coachscrews, Bolts or Threaded Rod Refer individual construction pages for further details. Fascia Board details below



4 - Face Fix directly Fascia Board then to Double Joists

5 - Gutter Bracket Face Fix directly to Fascia Board then into Double Joists



Notes re Mounting to Timber using a Preprimed Fascia


#### Fascia Specs

Must be Straight and true 180mm x 18mm Preprimed H3.1 Pine FJ. Painted, 15yr min durability.

Predrill 8mm dia + C/sink for No8 x 40mm SS C/S Woodscrews between mounting positions to hold the Fascia board in place.

You may predrill the Fascia board with all the Mounting holes if desired.

No Packing of Fascia Board, must be directly mounted to Boundary Joists



# Juralco Edgetec® Mini Post Balustrade System - Typical Fixing Complies with NZS3604:2011 - Double Boundary Joists

# Typical TOP Fix to Timber - JET 300, 110mm x 90mm, 4 hole Base Plate - M10 SS Coachscrews

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

			•		
Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fence applies to Top and Face Fix only					
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project Engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 Coachscrews 100mm min engagement into joists.
  Drill 6mm holes
- 4 Bond all coachscrews with SIKA Supergrip30 to full depth
- 5 Substructure shown indicatively only
- 6 All Fixings must be Stainless steel



# Juralco Edgetec® Mini Post Balustrade System - Typical Fixing Complies with NZS3604:2011 - Double Boundary Joists

# Typical TOP Fix to Timber - JET 305, 120mm x 100mm, 4 hole Base Plate - M10 SS C/S Coachscrews

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fence applies to Top and Face Fix only					
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project Engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 Coachscrews 100mm min engagement into joists.
  Drill 6mm holes
- 4 Bond all coachscrews with SIKA Supergrip30 to full depth
- 5 Substructure shown indicatively only
- 6 All Fixings must be Stainless steel



# Typical TOP Fix to Timber on Steel - JET 300, 110mm x 90mm, 4 hole Base Plate - M10 SS Bolts

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fence applies to Top and Face Fix only					
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes: Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 Substructure shown indicatively only
- 3 All fixings must be Stainless Steel



# Typical TOP Fix direct to Steel - JET 301, 120mm x 90mm, 2 hole Base Plate - M10 SS Bolts

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fence applies to Top and Face Fix only					
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes: Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL 4 Refer to Elevations for Max Panel widths



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 There must be a PVC Tape layer between the **Baseplate and Steel**
- 3 Substructure shown indicatively only
- 4 All fixings must be Stainless Steel



# Typical TOP Fix to Concrete Path - JET300, 110mm x 90mm, 4 hole Base Plate - M10 SS Studs

# Wind Zones (up to and including) Residential A, A Other and C3 only

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		


# Wind Zones (up to and including) Pool Fence only

Applies to Pool Fences not protecting a fall of 1.0m or more


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fen	Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths





- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 All fixings must engage the structural slab
- 3 A PVC Tape layer must be installed between the Baseplate and Concrete
- 4 Edge distance can be reduced to 75mm provided the Anchors are outside the Concrete slab cover and do not damage any reinforcement
- 5 Substructure shown indicatively only
- 6 All fixings must be Stainless Steel



# Typical TOP Fix to Concrete - JET 301, 120mm x 90mm, 2 hole Base Plate - M12 SS Studs

# Wind Zones (up to and including) Residential A, A Other and C3 only

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only

Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fen	Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	


- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths




### Installation details Fischer FIS V

Thread diameter M 12
Drill hole diameter = 14 mm
Drill hole depth = 100 mm
Anchorage depth = 90 mm
Drilling method Hammer drilling
Drill hole cleaning 4 times blowing, 4 times brushing,

4 times blowing No borehole cleaning required in case of using a hollow drill bit, e.g. fischer FHD.



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 All fixings must engage the structural slab
- 3 A PVC Tape layer must be installed between the Baseplate and Concrete
- 4 Substructure shown indicatively only
- 5 All fixings must be Stainless Steel



#### Typical TOP Fix to Concrete - JET 305, 120mm x 100mm, 4 hole Base Plate - M10 SS C/S Screws

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only

Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fen	Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm




### Installation details Fischer FBS II 8 x 80 C/S Screws


Thread diameter M10 Drill hole diameter = 8 mm Drill hole depth = 75 mmAnchorage depth = 65 mm

Drilling method Hammer drilling Drill hole cleaning Blow out by hand

No borehole cleaning required in case of using a hollow drill bit, e.g. fischer FHD.



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 All fixings must engage the structural slab
- 3 A PVC Tape layer must be installed between the **Baseplate and Concrete**
- 4 Edge distance can be reduced to 75mm provided the Anchors are outside the Concrete slab cover and do not damage any reinforcement
- 5 Substructure shown indicatively only
- 6 All fixings must be Stainless Steel



# Typical HIDDEN TOP Fix to Concrete - JET 304, 100mm x 100mm Base Plate, 4 x M10 SS Hidden Studs

# Wind Zones (up to and including) Residential A, A Other and C3 only

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		, ,
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only

Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fen	Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



### Installation details Fischer FIS V 300T

Thread diameter M10
Drill hole diameter = 12 mm
Drill hole depth = 70 mm
Anchorage depth = 60 mm


Drilling method
Drill hole cleaning

Hammer drilling 4 times blowing,


4 times brushing,

4 times blowing

No borehole cleaning required in case of using a hollow drill bit, e.g. fischer FHD.



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 All fixings must engage the structural slab
- 3 A PVC Tape layer must be installed between the Baseplate and Concrete
- 4 Edge distance can be reduced to 75mm provided the Anchors are outside the Concrete slab cover and do not damage any reinforcement
- 5 Substructure shown indicatively only
- 6 All fixings must be Stainless Steel



### Typical FACE Fix Post to Timber - M10 SS Coachscrews

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fen	Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project Engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 Coachscrews 90mm min engagement into joists.
  Drill 6mm holes
- 4 Bond all coachscrews with SIKA Supergrip30 to full depth
- 5 Substructure shown indicatively only
- 6 All Fixings must be Stainless steel



# Typical FACE Fix Post to Timber - M10 SS Bolts or M10 SS Threaded Rod

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500
High	12 T	1200	750	375
Very High	12 T	1200	600	300

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project Engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 Substructure shown indicatively only
- 4 All Fixings must be Stainless steel



# Typical FACE Fix Post Through a Cavity - M10 SS Coachscrews and Spacers

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fen	Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project Engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 Coachscrews 90mm min engagement into joists.
  Drill 6mm holes
- 4 Bond all coachscrews with SIKA Supergrip30 to full depth
- 5 Substructure shown indicatively only
- 6 All Fixings must be Stainless steel



# Typical FACE Fix to Steel, Wooden Packers - M10 SS Bolts

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
Pool Fence applies to Top and Face Fix only				ix only
Medium	12 T	1200	1000	500
High	12 T	1200	750	375
Very High	12 T	1200	600	300

- 1 General Notes: Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL 4 Refer to Elevations for Max Panel widths



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 A PVC Layer must be installed between the MiniPost and Steel Flange
- 4 Substructure shown indicatively only.
- 5 All fixings must be Stainless Steel



# Typical FACE Fix to Steel - M10 SS Bolts

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
Pool Fence applies to Top and Face Fix only				ix only
Medium	12 T	1200	1000	500
High	12 T	1200	750	375
Very High	12 T	1200	600	300

- 1 General Notes: Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL 4 Refer to Elevations for Max Panel widths



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 A PVC Layer must be installed between the MiniPost and Steel
- 3 Substructure shown indicatively only.
- 4 All fixings must be Stainless Steel



#### Typical FACE Fix to Concrete - M10 SS Studs

# Wind Zones (up to and including) Residential A, A Other and C3 only

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only

Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
Pool Fence applies to Top and Face Fix only				
Medium	12 T	1200	1000	500
High	12 T	1200	750	375
Very High	12 T	1200	600	300

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



# Installation details Fischer FIS V 300T

Thread diameter M10

Drill hole diameter = 12 mm

Drill hole depth = 160 mm

Anchorage depth = 150 mm


Drilling method
Drill hole cleaning

Hammer drilling 4 times blowing,


4 times brushing,

4 times blowing

No borehole cleaning required in case of using a hollow drill bit, e.g. fischer FHD.



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 All fixings must engage the structural slab
- 3 A PVC Tape layer must be installed between the MiniPost and Concrete
- 4 Substructure shown indicatively only
- 5 All fixings must be Stainless Steel



# Juralco Edgetec® Mini Post Balustrade System - Typical Fixing Complies with NZS3604:2011 - Double Boundary Joists

# Typical GUTTER BRKT FACE Fix to Timber - JET 137/65, Gutter Bracket - M10 SS Coachscrews

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
Pool Fence applies to Top and Face Fix only				ix only
Medium	12 T	1200	1000	500
High	12 T	1200	750	375
Very High	12 T	1200	600	300

- 1 General Notes:
- Glass thickness mm
- Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project Engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 Coachscrews 90mm min engagement into joists.
  Drill 6mm holes
- 4 Bond all coachscrews with SIKA Supergrip to full depth
- 5 Substructure shown indicatively only
- 6 All Fixings must be Stainless steel



# Juralco Edgetec® Mini Post Balustrade System - Typical Fixing Complies with NZS3604:2011 - Double Boundary Joists

# Typical GUTTER BRKT FACE Fix to Timber- JET 137/65, Gutter Bracket - M10 SS Bolts or M10 SS Threaded Rod

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
Pool Fence applies to Top and Face Fix only				ix only
Medium	12 T	1200	1000	500
High	12 T	1200	750	375
Very High	12 T	1200	600	300

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project Engineer must ensure the structure can support the appropriate loads
- 2 Timber SG8 minimum strength
- 3 Substructure shown indicatively only
- 4 All Fixings must be Stainless steel



# Typical GUTTER BRKT FACE Fix to Steel - JET 137/65, Gutter Bracket - M10 SS Bolts

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
High	12 T	1200			
Very High	12 T	1100			
	13.52SG	1200	720	250	
Extra High	13.52SG	1100			
Extra High	12T	1000			

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fence applies to Top and Face Fix only					
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 A PVC Tape layer must be installed between the Bracket and Steel
- 3 Substructure shown indicatively only
- 4 All fixings must be Stainless Steel



# Typical GUTTER BRKT FACE Fix to Steel, Wooden Packers - JET 137/65, Gutter Bracket - M10 SS Bolts

# Wind Zones (up to and including) Residential A, A Other and C3 only


Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only


Applies to Pool Fences not protecting a fall of 1.0m or more

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fence applies to Top and Face Fix only					
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
  - Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2- Timber SG8 minimum strength
- 3 Substructure shown indicatively only
- 4 All fixings must be Stainless Steel



# Typical GUTTER BRKT FACE Fix to to Concrete - JET 137/65, Gutter Bracket - M10 SS Studs

# Wind Zones (up to and including) Residential A, A Other and C3 only

Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)
High	12 T	1200		
Very High	12 T	1100		
very riigii	13.52SG	1200	720	250
Extra High	13.52SG	1100		
Extra High	12T	1000		

# Wind Zones (up to and including) Pool Fence only

Applies to Pool Fences not protecting a fall of 1.0m or more

· · · · · · · · · · · · · · · · · · ·					
Wind Zone	Glass Thickness, Type	Balustrade Height (max)	Clamp Spacing (max)	Glass Overhang (max)	
Pool Fence applies to Top and Face Fix only					
Medium	12 T	1200	1000	500	
High	12 T	1200	750	375	
Very High	12 T	1200	600	300	

- 1 General Notes:
  - Glass thickness mm
- Glass type T= Toughened, SG =SentryGlas
- 2 All measurements mm
- 3 Balustrade Height, above Deck/FFL
- 4 Refer to Elevations for Max Panel widths



### Installation details Fischer FIS V 300T

Thread diameter M10

Drill hole diameter = 12 mm

Drill hole depth = 80 mm

Anchorage depth = 70 mm


Drilling method
Drill hole cleaning

Hammer drilling 4 times blowing,


4 times brushing,

4 times blowing


No borehole cleaning required in case of using a hollow drill bit, e.g. fischer FHD.




- 1 The Project engineer must ensure the structure can support the appropriate loads
- 2 All fixings must engage the structural slab
- 3 A PVC Tape layer must be installed between the Bracket and Concrete
- 4 Substructure shown indicatively only
- 5 All fixings must be Stainless Steel



# Juralco 38mm Rectangular Interlinking Top Rail



Rectangular Interlinking Top Rail Part No JET/220/5.8 Also showing Infill Clip, for use in between Glass Panels



Interlinking Top Rail End Cap Part No JET 37



Interlinking Top Rail Gasket for 12 mmToughened Glass Part No JET/Gasket 12/2.9


### 1 - 12mm Glass and Gasket

#### **Application Notes:**


- Cut short lengths of Gasket (50mm) and place say every 700mm.
- Cut/adjust Interlinking rail to correct dimensions, test in place.
- Remove all, install full cut lengths of Gasket to glass top edge
- Assemble Top Rail + Joiners and suitable End plates
- Place blobs of V60 silicone in every Gasket hole
- Then place Top Rail extrusion + Joiners and End plates in place clipping firmly to Gasket
- Tape all down, wait 24 hrs to fully bond. Clean up.

Note: Ends must be attached to structure or post,

- Joins must have a suitable joiner plate



#### 2 - End Plate Brackets



End Plates: (After cutting extrusions to length)

- With End Plate in place, spot drill from below for position

- Use No 6 x 1/4in SS ST Pan sq drive Screw, 2 per plate.

- End Plate must be securely attached to Post or structure.


- Drill out to SS tab to 3mm dia, extrusion to 4mm dia

End Plate Tabs all 22.5 x 4mm SS.



JET 40LH

Interlinking Top Rail Wall type End Plate SS. 120x45mm



Interlinking Top Rail Wall type End Plate SS. 120x45mm JET 40RH




Interlinking Top Rail End Bracket SS. 60mm x 46mm JET 42

Important Note: All Interlinking rails, at their ends must be attached to a Building Structure or to an Edge Post attached to the Deck structure, using Rail End Plates/Brackets

## Juralco 38mm Rectangular Interlinking Top Rail - Corner Connectors and Joiners

#### 1 - Connectors



Swivel Kits: (After cutting extrusions to length)

- With Swivel in place, spot drill from below for position
- Drill out Swivel to 3mm dia, extrusion to 4mm dia
- Use No6 x 1/4in SS ST Pan sq drive screws, 2 x ea side of joint
- Both sides must be attached.

Both sides must be attached.
 Join together with the M6 x 25 C/S SS Screw

Interlinking Top Rail Horizontal Fixed 90 deg Connector JET 45A





Interlinking Top Rail


Horizontal 0 - 90deg


Swivel Connector

JFT 46B












Interlinking Top Rail Horizontal 0 - 90deg Swivel Connector JET 46A



Rectangular Interlinking Top Rail Horizontal 0 - 90 deg Right/Left Swivel Connector Kit JET220/Horizontal Adj Corner Kit (JET 46A and B + screw)






Interlinking Top Rail Vertical 35deg up to 35 deg down Swivel Connector JET 47A








Interlinking Top Rail

Vertical 35deg up











# 2 - Joiners



Joiners: (After cutting extrusions to length)

- With Joiner in place, spot drill from below for position
- Drill out to joiner to 3mm dia, extrusion to 4mm dia
- Use No 6 x 1/4in SS ST Pan sq drive screws, 2 x ea side of joint
- Both ends must be attached.
- Joins, where required must be at the end of Glass Panels




Interlinking Top Rail Straight Joiner 80x22.8x5mm JET 30

Interlinking Top Rail Corner Joiner 75x75x5mm JET 31


Joiners both 22.5 x 5mm Aluminium




## **Juralco 50mm Round Interlinking Top Rail**



Round Interlinking Top Rail Part No JET/211/5.8 Also showing Infill Clip, for use in between Glass Panels



Round Interlinking Top Rail End Cap Part No JET/231



Interlinking Top Rail Gasket for 12 mmToughened Glass Part No JET /Gasket 12/2.9


#### 1 - 12mm Glass and Gasket

# **Application Notes:**


- Cut short lengths of Gasket (50mm) and place say every 700mm.
- Cut/adjust Interlinking rail to correct dimensions, test in place.
- Remove all, install full cut lengths of Gasket to glass top edge
- Assemble Top Rail + Joiners and suitable End plates
- Place blobs of V60 silicone in every Gasket hole
- Then place Top Rail extrusion + Joiners and End plates in place clipping firmly to Gasket
- Tape all down, wait 24 hrs to fully bond. Clean up.

Note: Ends must be attached to structure or post,

- Joins must have a suitable joiner plate



#### 2 - End Plate Brackets



End Plates: (After cutting extrusions to length)

- With End Plate in place, spot drill from below for position


- Use No 6 x 1/4in SS ST Pan sq drive Screw, 2 per plate - End Plate must be securely attached to Post or structure.

- Drill out to SS tab to 3mm dia, extrusion to 4mm dia

End Plate Tabs all 22.5 x 4mm SS.



Interlinking Top Rail Wall type End Plate SS. 120x45mm JET 40LH




Interlinking Top Rail Wall type End Plate SS. 120x45mm JET 40RH



Interlinking Top Rail End Bracket SS. 60mm x 46mm JET 42

# Juralco 38mm Rectangular and 50mm Round Interlinking Top Rail - End Bracket Attachments

Applies to 38mm Rectangular and 50mm Round InterlinkingTop Rails only




Round Interlinking Top Rail Extrusion JET/211/5.8

Interlinking Top Rail Extrusion JET/220/5.8

#### Interlinking Top Rail End Bracket Options - Both types above - Tab attach Type








Interlinking Top Rail Wall type End Plate SS. 120x45mm JET 40RH



Interlinking Top Rail End Bracket SS. 60mm x 46mm JFT 42

#### Interlinking Top Rail End Bracket Options - Round Type only - Attach into Screw ports



Interlinking Top Rail Wall type offset End Plate Round Rail type only 120x42x3mm, Al C/s both sides = RH or LH JET 233



Interlinking Top Rail Wall type End Plate Round Rail type only 50x58x5mm, Al JET 232

Tabs all 22.5 x 4mm SS. Front faces all 3mm SS

#### **General Notes:**

- All fixings to be Stainless Steel PVC Tape layer between Structure and Bracket
- ULS Point load N\* = 0.9kN, inwards, outwards or down and in tension

# Note : Fixing to Steel

- use 2 off 8g SS TEK Screws or M6 SS Bolts
- Steel 2mm min thickness
- Steel 300MPA minimum
- 15mm min distance to any Edges

#### Note: Fixing to Timber Wall

- use 2 off 8g SS Screws, 35mm min into studs.
- use Sika Supergrip 2hr
- 30mm min distance to Horizontal Edge
- If Weatherboard use suitable predrilled Wedge
- Timber stud wall to be designed and detailed in accordance with NZS1720.1:2022 Timber Structures Part 1 - Design methods or NZS3604

#### Note: Fixing to Juralco EDGE Post

- use 2 off 8g x 25 SS PK Screws

# Note: Fixing to Concrete Wall


- use 2 off M6 x70 SS Screw Anchors
- Solid Concrete min 20Mpa
- Block wall Concrete filled/Reinforced
- 140mm min Wall thickness
- 70mm min distance to Horizontal Edge
- 100mm min distance to Vertical Edge
- Blockwork wall must be corefilled /reinforced and is to be designed and detailed in accordance with NZS4230 or NZS4229




# Small SS Interlinking Top Rail

# V60 Silicone Joining Top Rail, Gasket and Glass Small Interlinking Top Rail Gasket Glass Panel 12mm Toughened

# 25mm SS Interlinking Top Rail



SMALL SS INTERLINKING TOP RAIL GASKET JET/490GT/12/2.9 (Black)




SMALL SS INTERLINKING TOP RAIL JET/490/5.8/SSS JET/490/5.8/SCC Duplex 2205

Grub Screws,

# 25mm SS Interlinking Rail Connections

Note: All these Brackets use M5 x 6 SS Grub Screws. If necessary these holes must be Drilled + tapped M5, as shown. The under side of the Interlinking Rail must be drilled M6 to match M5 tapped holes positions, for access to Grub screws - Joins, where required must be at the end of Glass Panels Available as Satin(SSS) or Powdercoated SCC finishes







180deg INLINE JOINER Duplex 2205 JET491/SCC JET491/SSS 21mm x 25mm x 51mm deep




END CAP Duplex 2205 JET492/SSS JET492/SCC 21mm x 25mm x 25mm deep




90deg JOINER Duplex 2205 JET493/SSS JET493/SCC 21mm x 80mm x 80mm




+90 to - 45 deg ADJUSTABLE HORIZONTAL JOINER Duplex 2205 JET494/SSS JET494/SCC 21mm x25mm x 75mm overall deep





+90 to - 45 deg ADJUSTABLE VERTICAL JOINER Duplex 2205 JET495/SSS JET495/SCC 21mm x25mm x 73mm overall deep



# Brackets for Fixing to Wall or End Post for 25mm SS Interlinking Rail







Note: All these Brackets use M5x6mm SS Grub Screws



WALL BRACKET Duplex 2205 JET496/SSS JET/496/SCC 68mm x 28mm x 30mm deep



WALL BRACKET - RH. Duplec 2205 JET497/RH/SSS JET497/RH/SCC 41mm x 47mm x 30mm deep



WALL BRACKET - LH Duplex 2205 JET497/LH/SSS JET497/RH/SCC 41mm x 47mm x 30mm deep

## **General Notes:**

- All fixings to be Stainless Steel. PVC Tape layer between Structure and Bracket
- ULS Point load N\* = 0.9kN, inwards, outwards or down and in tension

# Note: Fixing to Steel

- use 2 off 8g SS TEK Screws or M6 SS Bolts
- Steel 2mm min thickness
- Steel 300MPA minimum
- 15mm min distance to any Edges

# Note: Fixing to Timber Wall

- use 2 off 8g SS Screws, 35mm min into studs.
- use Sika Supergrip 2hr
- 30mm min distance to Horizontal Edge
- If Weatherboard use suitable predrilled Wedge
- Timber stud wall to be designed and detailed in accordance with NZS1720.1:2022 Timber Structures Part 1 - Design methods or NZS3604

## Note: Fixing to Juralco EDGE Post


- use 2 off 8g x 25 SS PK Screws

#### Note: Fixing to Concrete Wall


- use 2 off M6 x70 SS Screw Anchors
- Solid Concrete min 20Mpa
- Block wall Concrete filled/Reinforced
- 140mm min Wall thickness
- 70mm min distance to Horizontal Edge
- 100mm min distance to Vertical Edge
- Blockwork wall must be corefilled /reinforced and is to be designed and detailed in accordance with NZS4230 or NZS4229




# Juralco 40mm SS Interlinking Top Rail



SS Interlinking Top Rail 12mm Glass Gasket JET/430GT/12/2.9




SS INTERLINKING TOP RAIL JET/430/PSS/5.8




# 40mm SS Interlinking Rail Connectiors

Note: All these Brackets use M5 x 6 SS Grub Screws. If necessary these holes must be Drilled + tapped M5, as shown.

The under side of the Interlinking Rail must be drilled M6/7 to match M5 tapped holes positions, for access to Grub screws - Joins, where required must be at the end of Glass Panels







180deg INLINE JOINER 2205 JET/431/PSS 60mm x 40mm x 30mm deep




END CAP 2205 JET/432/PSS 33mm x 40mm x 30mm deep



90deg JOINER 2205 JET/433/PSS 95mm x 95mm x 30mm deep




+90 to - 45 deg ADJUSTABLE HORIZONTAL JOINER 2205 JET/434/PSS 70mm x 70mm x 30mm deep





+90 to - 45 deg ADJUSTABLE VERTICAL JOINER 2205 JET/435/PSS 60mm x 60mm x 40mm wide


## Juralco 40mm SS Interlinking Top Rail - End Brackets




# Brackets for Fixing to Wall or End Post for 40mm SS Interlinking Rail















WALL BRACKET 2 FIX 2205 Part No JET/436/PSS 87mm x 37mm x 25mm deep

WALL BRACKET 2 FIX - RH 2205 Part No JET/437/RH/PSS 52mm x 60mm x 33mm deep

WALL BRACKET 2 FIX - LH 2205 Part No JET/437/LH/PSS 52mm x 60mm x 33mm deep

#### **General Notes:**

- All fixings to be Stainless Steel PVC Tape layer between Structure and Bracket
- ULS Point load N\* = 0.9kN, inwards, outwards or down and in tension

#### Note: Fixing to Steel

- use 2 off 8g SS TEK Screws or M6 SS Bolts
- Steel 2mm min thickness
- Steel 300MPA minimum
- 15mm min distance to any Edges

#### Note: Fixing to Timber Wall

- use 2 off 8g SS Screws, 35mm min into studs.
- use Sika Supergrip 2hr
- 30mm min distance to Horizontal Edge
- If Weatherboard use suitable predrilled Wedge
- Timber stud wall to be designed and detailed in accordance with NZS1720.1:2022 Timber Structures Part 1 - Design methods or NZS3604

# Note: Fixing to Juralco EDGE Post

- use 2 off 8g x 25 SS PK Screws

#### Note: Fixing to Concrete Wall

- use 2 off M6 x70 SS Screw Anchors
- Solid Concrete min 20Mpa
- Block wall Concrete filled/Reinforced
- 140mm min Wall thickness
- 70mm min distance to Horizontal Edge
- 100mm min distance to Vertical Edge
- Blockwork wall must be corefilled /reinforced and is to be designed and detailed in accordance with NZS4230 or NZS4229





## **Juralco Glass Panel Stiffener Brackets**


This page applies 13.52 SentryGlas only

Top Edge, Frameless Glass Stiffeners.

- Install 200mm max from Glass Top edge
- Supplied as a kit, with screws, a variety of Gaskets and a SS clamp Plate
- Duplex 2205 SS construction.
   Polished (PSS), Satin (SSS)
   or Powder coat SCC Finishes









#### Notes:


- All fixings to be stainless steel
- Timber stud wall to be designed by Project structural engineer for loads imposed by Balustrade.
- ULS Point load  $N^* = 0.9kN$ , inwards, outwards or down.
- Minimum Stud size = 90mm x 45mm
- Minimum Timber grade = SG8
- -Timber stud wall to be designed and detailed in accordance with NZS1720.1:2022 Timber Structures Part 1 - Design methods or NZS3604






#### Notes:


- All fixings to be stainless steel
- Blockwall to be designed by Project structural engineer for loads imposed by Balustrade.
- ULS Point load  $N^* = 0.9kN$ , inwards, outwards or down.
- Minimum blockwork thickness = 140mm
- Minimum core fill concrete strength = 17.5MPa
- Blockwork wall must be corefilled /reinforced and is to be designed and detailed in accordance with NZS4230 or NZS4229






# Juralco MiniPost® Balustrade System Interlinking Top Rail for attaching to a Edge balustrade End Post where Wall fixing not suitable

Applies to InterlinkingTop Rails suitable for 12mm Toughened Glass



## **Juralco Interlinking Rails**








AEROFOIL HANDRAIL JEB/217/5.8




ROUND HANDRAIL JEB/209/5.8



RECTANGULAR HANDRAIL JEB/216/5.8




CIRCULAR HANDRAIL JEB/221/5.8



CIRCULAR HANDRAIL JEB/223/5.8 + Clip JEC38

Suitable Interlinking Rail and Handrails (as Interlinking Rails)


# Interlinking or Handrails on Deck side.




**Frameless Glass Systems** 

Important Note: All Interlinking rails, at their ends must be attached to a Building Structure or to an Edge Post attached to the Deck structure, using Rail End Plates/Brackets. Applies to Handrails used as Interlinking Rails


## **Juralco Handrail Components - Joiners**




All ex 3mm Aluminium



Rectangular and 75m Aerofoil Inline Joiner Use 56.5 x 3 flat bar JA/189/5.0






Rectangular and 75m Aerofoil 90deg Corner Joiner JEC 01


# Round and Circular Handrail, End Cap, Straight and 90deg corners

All ex 3mm Aluminium




AEROFOIL HANDRAIL






Round and Circular 90deg Corner Joiner JEC 04

Use No6 x 1/4in SS pan sq drive screws, 2 ea side of joint




End Caps for Handrails, Wall or Edge Post attach for JEB 222, 217, 209, 216 and 221 Handrails


End Caps all ex 3mm Aluminium




HANDRAIL Part No JEB/222/5.8




AEROFOIL HANDRAIL Part No JEB/217/5.8




RECTANGULAR HANDRAIL Part No JEB/216/5.8




HALF ROUND HANDRAIL Part No JEB/209/5.8




CIRCULAR HANDRAIL Part No JEB/221/5.8




HANDRAIL WALL ATTACH END PLATE Part No JEC215/WC




HANDRAIL WALL ATTACH END PLATE Part No JEC217/WC




HANDRAIL WALL ATTACH END PLATE Part No JEC216/WC




HANDRAIL WALL ATTACH END PLATE Part No JEC209/WC




HANDRAIL WALL ATTACH END PLATE Part No JEC221/WC




For RH and LH




For RH and LH



For RH and LH



For RH and LH



For RH and LH

**General Notes:** - All fixings to be Stainless Steel. - EPDM layer between Structure and End Cap - ULS Point load  $N^* = 0.9kN$ , inwards, outwards or down and in tension

#### Note: Fixing to Steel

- use 2 off 8g SS TEK Screws or M6 SS Bolts
- Steel 2mm min thickness
- Steel 300MPA minimum
- 15mm min distance to any Edges

#### Note: Fixing to Timber Wall

- use 2 off 8g SS Screws, 35mm min into studs.
- use Sika Supergrip 2hr
- 30mm min distance to Horizontal Edge
- If Weatherboard use suitable predrilled Wedge
- Timber stud wall to be designed and detailed in accordance with NZS 1720.1:2022 Timber Structures Part 1 - Design methods or NZ3604

#### Note: Fixing to Juralco EDGE Post

- use 2 off 8g x 25 SS PK Screws

#### Note: Fixing to Concrete Wall

- use 2 off M6 x70 SS Screw Anchors
- Solid Concrete min 20Mpa
- Block wall Concrete filled/Reinforced
- 140mm min Wall thickness
- 70mm min distance to Horizontal Edge
- 100mm min distance to Vertical Edge
- Blockwork wall must be corefilled /reinforced and is to be designed and detailed in accordance with NZ4230 or NZ4229

# Juralco Edgetec® Mini Post Balustrade System Glass Care and Maintenance

#### **Glass Cleaning and Maintenance**

Architectural glass products must be properly cleaned during the construction period so visual and aesthetic clarity are maintained. Because glass can be permanently damaged if improperly cleaned, glass producers and fabricators recommend strict compliance with the following procedures.

First, determine whether the glass is clear, tinted or reflective. Surface damage is more noticeable on reflective glass compared with the other glass products. If the reflective coated surface is exposed, either on the exterior or interior, special care must be taken when cleaning, as scratches can result in coating removal and a visible change in light transmittance. Cleaning tinted and reflective glass in direct sunlight should be avoided. Cleaning should begin at the top of the building and continue to the lower levels.

Commence cleaning by soaking the glass surfaces with clean water and a soap solution to loosen dirt or debris. Then, using a mild, non-abrasive commercial window washing solution, uniformly apply the solution to the glass surfaces with a non-abrasive applicator and follow with a squeegee to remove all of the cleaning solution from the glass surface.

Ensure that no metal parts of the cleaning equipment touch the glass surface and that no abrasive particles are trapped between the glass and the cleaning materials. All water and cleaning solution residue should be dried from the window gaskets, sealants and frames.

#### **Scratches and Metal Scrapers**

Scratches can occur from hard pointed objects or poor handling, but most often occurs from the careless removal of foreign matter from the glass surface.

Mortar splatter and paint are common offenders and efforts to remove after hardening almost always lead to surface damage. It is essential that the foreign materials are removed before they harden. Better still, if construction work continues after glazing, that the glazed areas are protected by adhesive plastic films or suitable tarpaulins or covers.

One of the common mistakes made by non-glass trades people, including glass cleaning contractors, is the use of razor blades or other metal scrapers on a large portion of the glass surface. Using large blades to scrape a window clean carries considerable risk of causing damage to the glass.

The glass industry, fabricators, distributors and installers neither condones nor recommends any scraping of glass surfaces with metal blades or knives. Such scraping usually permanently damages or scratches the glass surfaces. When paint or other construction materials cannot be removed with normal cleaning procedures, a new 25mm razor blade may have to be used. The razor blade should be used on small spots only. Cleaning should be done in one direction only. Never scrape in a back and forth motion as this could trap particles under the blade that could scratch the glass.

Blades or scrapers can dislodge "pickup" on toughened glass. There are fine particles of glass that are fused on to the surface during toughening. Once dislodged they can scratch the glass.

# Glass Cleaning, Do's and Don'ts

#### DO NOT.

- Do Not Use Scrapers of any type or size on a Glass surface
- Do Not Leave building dirt or residues to remain on Glass for a period of time.
- Do Not Begin cleaning glass until you have identified the surface type.
- Do Not Clean Glass surfaces in direct sunlight.
- Do Not Allow dirty water or cleaning residues to remain on the Glass.
- Do Not Begin cleaning before rinsing off a loose residues.
- Do Not Use abrasive cleaning solutions, materials or solvents.
- Do Not Allow metal parts of the cleaning equipment to come in contact with the Glass.
- Do Not Trap abrasive particles between the cleaning material and the Glass.

#### DO...

- Clean glass promptly when dirt or building residues appear.
- Determine glass surface type.
- Exercise special care when cleaning coated surfaces.
- Avoid cleaning glass surfaces in direct sunlight.
- Start cleaning at the top of a building, then continue to lower levels.
- Soak the glass surface in a clean soapy solution before cleaning.
- Use a mild non abrasive commercial cleaner.
- Use a squeege to remove all cleaning solution.
- Try your procedures on a small window and check.
- Caution other trades re the care and protection of the glass surfaces.

Residues of surface grit may be present from the toughening production process.

These grit particles must not be dragged across the surface.

NEVER use Metal Scrapers

All above reprinted with permission from Metro Glass Tech



# Juralco Edgetec® Mini Post Balustrade System **Powder Coating Care and Maintenance**

# **Powder Coating Installation Care**

#### Warning re use of solvents:

- In some cases strong solvents are recommended for thinning various types of paints and also for cleaning up mastics and sealants.
- These can be harmful to the extended life of the powder coated surface, and must not be used for cleaning purposes.
- It is important to note that the damage will not be visible immediately and may take up to I2 months to develop.

If paint splashes or sealants and mastics need to be removed then the following may be safely used: Methylated Spirits, Ethyl Alcohol, Isopropanol or preferably a mild detergent in warm water.

#### Joinery Protection during Installation:

All the activity on a construction site means that your powder coated items may get knocked or scratched, splattered with mortar, plaster, textured coating or paint during the later stages of construction.

Please ensure that all powder coated articles are masked or covered at this time. It is far easier to prevent accidents than to try and correct them. Should your joinery receive mortar or paint splashes see that these are removed before cure and follow the instructions contained in this brochure.

Typical sticker used to warn other trades of the need to protect and mask off powder coated joinery (applies to anodised joinery also)

#### "IMPORTANT ALL TRADES"

This valuable aluminium joinery will suffer permanent damage from: plaster, mortar and paint splashes - Protect if splashes occur - Immediately wash down joinery with water or meths - Do not allow splashes to harden! ~ Do not use solvents! - Do not remove this label until final clean completed.

This photograph display damage that has occurred on site, post installation. The photo of the masked joinery displays clear signs of damage that could have occurred were it not masked. Please ensure that your joinery is protected right through the entire construction process.



#### **Powder Coating Maintenance**

#### **External - Maintenance Program:**

To extend the life of external powder coated articles and to comply with warranty requirements for powder coated aluminium joinery, a simple, regular maintenance program must be implemented.

The effects of ultra violet light, atmospheric pollution, dirt, grime and airborne salt deposits will all accumulate over time and must be removed or surface staining and weathering will occur, leading to an unsightly appearance.

For external coatings, cleaning should take place every six months. In areas where pollutants are more prevalent, such as beachfront houses and industrial or geothermal areas, then a cleaning program should be carried out on a more frequent basis ie. every one to three months.

Fences or Balustrades in close proximity to swimming pools must be washed down every six months, to clean off chlorine and salt deposits.

#### Cleaning your powder coating:

- 1. Carefully remove any loose surface deposits with a wet sponge.
- 2. Use a soft brush (non abrasive) and a mild household detergent (do not use solvents) in warm water, remove dust, salt and other deposits.
- 3. Rinse off with clean fresh water.

#### Restoring weathered or scratched surfaces:

Repair of Scuffed or Scratched surfaces

Dulux Spray Cans are available in all colour card colours.

Repair of Small Scratches or Chips.

Dulux Dabsticks are ideally suited for the repair of small scratches. Dabsticks may not be available in all colour card colours.

Repair of Weathered areas .

Dulux Gloss Up is a light to medium cutting cream ideally suited for gloss restoration and has been specifically designed for this purpose. Gloss Up contains no waxes or silicone and is a one step system.

Contact Dulux Powder Coatings, ph 0064 9 441 8244





# Juralco Edgetec® Mini Post Balustrade System Stainless Steel Care and Maintenance

#### Care and Maintenance of Stainless Steel

Introduction

Stainless steels are selected for applications where their inherent corrosion resistance, strength and aesthetic appeal are required. However, dependent on the service conditions, stainless steels will stain and discolour due to surface deposits and so cannot be assumed to be completely maintenance-free. In order to achieve maximum corrosion resistance and aesthetic appeal, the surface of the stainless steel must be kept clean. Provided the grade of stainless steel and the surface finish are correctly selected, and cleaning schedules carried out on a regular basis, good performance and long service life will result.

For the correct selection of a Stainless Steel grade, with respect to Location, see Table below.

#### **Factors affecting maintenance**

Surface contamination and the formation of deposits on the surface of the stainless steel must be prevented. These deposits may be minute particles of iron or rust generated during construction. Industrial and even naturally occurring atmospheric conditions can produce deposits which can be equally corrosive, e.g. salt deposits from marine conditions.

Working environments can also provide aggressive conditions such as heat and humidity in swimming pool buildings. These conditions can result in surface discolouration of stainless steels and so maintenance on a more frequent basis may be required.

Modern processes use many cleaners, sterilizers and bleaches for hygienic purposes. Proprietary solutions, when used in accordance with makers' instructions, should be safe but if used incorrectly (e.g. warm or concentrated), may cause discolouration or corrosion on stainless steels. Strong acid solutions are sometimes used to clean masonry and tiling of buildings. These acids should never be used where contact with metals, including stainless steel, is possible. If this happens, the acid solution must be removed immediately, followed by dilution and rinsing with clean water.

#### Maintenance programme

With care taken during fabrication and installation, cleaning before 'hand-over' should not present any problems. More attention may be required if the installation period has been prolonged or hand-over delayed. Where surface contamination is suspected, immediate cleaning after site fixing should avoid problems later.

The frequency of cleaning is dependent on the application. This may vary from once to four times a year for external applications, Recommendations on cleaning frequencies in architectural applications are shown below.

#### Cleaning frequency

Reccommended Cleaning for various grades of Stainless Steel		
Location	304 Grade	316 Grade
Surbarban or Rural	Clean at 6-12mth intervals or as necessary	
Industrial or Urban	Clean at 3-6mth intervals	Clean at 6-12mth intervals
Coastal or Marine	Not recommended	