

9071

Sanimulti



(EN) Macerator pump • Operating/installation manual



CONTENTS

1. S <i>A</i>	l. SAFETY3				
2. RE	ECOMMENDEND USE	3			
3. DI	. RECOMMENDEND USE 3 . DESCRIPTION 3 3.1 Technical data 3 3.2 Flow characteristics 3 3.3 PUMPING DISTANCE PERFORMANCE 3 3.4 DIMENSIONS 3 . INSTALLATION 4 4.1 Connecting P trap, wall face or wall-mounted pan installation 4 4.2 Important removing accessories 4 4.3 Relocating pan inlet connector 5 4.4 Pump line connection 7 4.5 Venting 7 4.6 Additional connections 9 4.7 Fixing 10 4.8 Connecting a shower 10				
3.1	TECHNICAL DATA	3			
3.2	FLOW CHARACTERISTICS	3			
3.3	Pumping distance performance	3			
3.4	DIMENSIONS	3			
4. IN	STALLATION	4			
4.1	CONNECTING P TRAP, WALL FACE OR WALL-MOUNTED PAN INSTALLATION	4			
4.2	IMPORTANT REMOVING ACCESSORIES	4			
4.3	RELOCATING PAN INLET CONNECTOR	5			
4.4	Pump line connection	7			
4.5	Venting	7			
4.6	Additional connections	9			
4.7	FIXING	. 10			
4.8	CONNECTING A SHOWER	. 10			
4.9	HIGH LEVEL CONTROL SANIALARM INTERLOCK CONNECTION (OPTIONAL)	11			
5. TF	ROUBLE SHOOTING GUIDE	11			
6. W	ARRANTY	11			

1. SAFETY



DISCONNECT ELECTRICAL POWER BEFORE WORKING ON THE PUMP!

Plumbers/Contractors, please ensure a copy of the installation instructions is left with the end user for future reference.

2. RECOMMENDEND USE

The Sanimulti is a compact versitile macerator pump designed for light - medium commercial use. The unit is designed to receive and pump away waste water from a WC, bath, shower & basin.

NOTICE



- DO NOT dispose of solvents, paints, turps, caustic acid, or other corrosive acids or cleaners.
- DO NOT dispose of hot water in excess of 60°C.
- DO NOT use cleaning products that produce excessive foam, this may cause motor damage.
- DO NOT install in a hairdressing salon without the use of a hair trap first.
- DO NOT dispose of paper hand towels, sanitary napkins or wet wipes .
- DO NOT dispose of forign objects or use excessive amounts of toilet paper .


3. DESCRIPTION

3.1 TECHNICAL DATA

Product Code and Description	SA222 - Sanimulti light commercial macerator pump
Electrical Power Supply	220 - 240 V 50 Hz
Nominal Current	2.5 A
Motor Power Rating	560 W
Vertical Pumping Height	Up to 8 meters
Horizontal Pumping Distance	Up to 70 meters
Maximum Temperature	40°C

Inlets	3 + 2 optional
Recommended Waster Water pipe	DN25
Inlet Diameter	DN100 - 40mm
Venting	Optional external vent connection
Alarm	Included
Casing	White
Dimensions	505 x 361 x 205 mm (W x H x D)

3.2 FLOW CHARACTERISTICS




3.3 PUMPING DISTANCE PERFORMANCE


NOTE

1% fall minimum required on the horizontal run.

Pipe size must be increased by 1 size minimum after the first 5 meters of horizontal run.



3.4 DIMENSIONS



4. INSTALLATION

- The macerator pump should be installed to allow full access in the event that servicing or removal is required. Where the unit is concealed in the wall cavity a 500mm access panel must be provided
- The unit must be located on the same floor as the fittings it is to service.
- All incoming pipework must have a constant gradient of 1:40.
- The unit has 2 lower lateral inlet ports. If an inlet is not in use, cap off the inlet with side plug.
- The top of the unit has a dedicated vent point with interated carbon filter to neutralise odors, this point can also be used as optional external vent to atmosphere connection point.
- Where possible, venting should always be consistent to current plumbing venting requirements as per AS 3500.
- · Before commissioning the unit, make sure all connections are secure and water tight.
- The electrical installation should be carried out by a registered eletrician in accordance with AS/NZS 3000.
- AAV valves are not an alternative to venting to atmosphere as the unit needs to have two way venting for correct activation function.

4.1 CONNECTING P TRAP, WALL FACE OR WALL-MOUNTED PAN INSTALLATION

In delivered condition the pump comes assembled with the toilet connection already prepared side entry (Fig 1), use supplied pan connector for standard P trap toilet suite or to connect to 100 mm DWV pipe for remote installation (wall hung pan etc.). If direct connection to toilet pan is required configuration can be changed to (Fig 2).

Fig 1:






Fig 2:



4.2 IMPORTANT REMOVING ACCESSORIES





NOTE

Check to see that all accessory parts are taken out of the pump unit!


Unit	Individual part	Fig.
	Collecting tank incl. pump with comminutor and connecting cable, 1.3 m long (connected to the pump motor) potential-free contact with 0.25 m cable	
Accessories	Sealing sleeve DN 852 x hose clips 80-100	
	 Union nut Pressure socket M32 x 2 Pressure outlet 1½" internal thread 90° elbow Safety nut with check valve HT long sleeve DN 40 Double nipple 1½" 1 x rubber flat seal DN 40 1 x rubber flat seal DN 32 2 x sealing sleeves DN 40 Multi hose connection DN 28 DN 32 5 x hose clips 40-60 1 x hose clip 25-40 	
	 4 x buoyancy control with 4 nail plugs Extraction tool for the inlets Sticker 	

4.3 RELOCATING PAN INLET CONNECTOR






6. Counterhold the separation wall at the pressure point and fix it in such a way that the groove of the inner threaded ring snaps in at the bar in the inlet opening. Now the cover can be screwed in using the special tool



7. Here, too, pay attention to the correct position of the threaded ring; the groove faces towards the front; screw in the inlet by hand




- <u>8.</u> ▷ install the sealing sleeve DN 85 and the hose clip 80 100 at the front, tighten the clip
- 9. \triangleright Insert the pump
- 10. Close the cover

4.4 PUMP LINE CONNECTION

The pressure line is fed out at the top from the device.


According to the installation conditions, the pressure outlet can be fed out straight or by using a 90° elbow. Using the included hose clips, the pressure line is connected and fixed. The pressure line must have a minimum internal diameter of 20 mm.

The correct installation position of the discharge elbow with integrated non-return valve must be observed. A PVC pressure ball must be installed on the pump line for isolation to facilitate servicing.




Pressure line, outlet with 90° elbow, can be turned to any directions


4.4.2 Connection option with double threaded nipple 1 1/4":



- 1. Unscrew the plastic thread from the supplied safety nut by means of the special tool
- 2. > and insert the double threaded nipple instead
- 3. busing the union nut, fasten it on the pump pressure socket (straight or 90°) and connect the pressure line



Pressure line, straight outlet




Pressure line, outlet with 90° elbow, can be turned to any directions


4.5 VENTING

This pump comes with an integrated active carbon filter with anti flood valve, the active carbon in the filter is designed to neutralize odor emitted during the course of normal hydraulic function. Where possible, venting should always be consistent to current plumbing venting requirements as per AS 3500.

Position of venting (with activated carbon) upon delivery:



Changing the venting position:



1. using the special tool, take out the two upper inlet covers, position 1 and e.g. position 3 (the position numbers 1, 2 and 3 can be seen inside the inlet covers)







2. ▷ take out the inner valve insert with ball and the inner inlet insert. To do so, insert the special tool inside the groove, turn it anti-clockwise by 10° and pull it out



3. > now insert the valve insert with ball by hand into the inner groove (position 3) and, using the special tool, tighten it by turning it approx. 10° clockwise. Likewise, insert the inner inlet insert to position 1 and tighten it



4. busing a screwdriver, press the activated carbon out of the cover no. 1 and insert it into the cover no. 3



5. > now put the cover no. 1 (without activated carbon) and cover no. 3 (with activated carbon) back to the respective position; when inserting, pay attention to the groove


4.6 ADDITIONAL CONNECTIONS

4.6.1 Upper connections






- 1. ▷ by means of the special tool, now pull out the inner inlet; while doing so, turn the tool in the groove about 10° anti-clockwise and pull upward
- 2. > the inner inlet is still closed; using a cutter knife, cut open the bottom of the inlet




- 3. ▷ insert the opened inner inlet by hand in the groove
- 4. ▷ now with the special tool in the groove, tighten by turning it approx. 10° clockwise
- 5. ▷ insert the seal and the supplied long sleeve HT DN 40 by hand

4.6.2 Lateral inlets


The lateral inlets for the connection of a shower:






1. The "noses" on the lateral inlet cover must face to the left and right (horizontally); the cover can be removed by hand only in this position


- 2. ▷ attach the supplied sealing sleeve DN 40 and the hose clip 40 - 60
- 3. \triangleright using a cutter knife, cut the sealing sleeve to the correct length or cut open



4. ▷ then install the sealing sleeve with a hose clip 40 - 60 on the lateral inlet nozzle, and with a second hose clip 25 - 40, fasten the sealing sleeve and the inlet line of a shower, for example



4.7 FIXING





The pump can be firmly secured to the floor using the supplied fixation brakets and tap screws.

4.8 CONNECTING A SHOWER




When connecting a shower to the **Sanimulti** the shower must be elevated to a height of no less than 170 mm from the shower grate to the base of the pump on finished floor level whilst maintaining 1:40 or 3% gradient on the shower waste fixture line.

4.9 HIGH LEVEL CONTROL SANIALARM INTERLOCK CONNECTION (OPTIONAL)

Fig 1 shows Sanialarm Interlock has a socket connection marked «Quick plug float switch». Plug one end of supplied accessory lead to this connection, as indicated. Plug the other end of supplied lead to connection indicated on the pump (Fig 2). Finish connecting Sanialarm Interlock as per instructions supplied with alarm.

Fig 1: Fig 2:



5. TROUBLE SHOOTING GUIDE



For repair and maintenance works on the pump, always disconnect the power plug from the power socket.

Malfunction	Cause	Troubleshooting
Motor does not run	Supply voltage missing	Check the socket
		Insert the power plug
	Cutting knife blocked	Remove/clear object, test run
	Motor overloaded	Thermal protection switches off the motor, in case of recurrence, remedy by qualified staff/customer service
	Control defective	Remedy by qualified staff/ customer service
	Motor defective	Replacement (customer service)
Motor runs,	Discharge pressure line blocked	Clear blockages, carry out test run
but waste will not discharge	Pump ventilation clogged	Pull off pump ventilation hose, clean hose and nozzle
discharge	Check valve incorrectly installed	Rotate, check function
	Tank ventilation clogged	Replace activated carbon filter
Motor runs in short in-	Ventilation clogged	Pull off pump ventilation hose, clean hose and nozzle
tervals	Check valve leaking	Clean or replace check valve
	Cistern valve leaking	Rectify/replace
Motor makes loud foreign or rattling noise	Foreign object has got into the device	Remove/clear object, test run
Alarm sounds	Too high filling level	Check for power disconnection, blockages and contact Saniflo Technical for service/assistance

6. WARRANTY

2 YEAR WARRANTY

This device is guaranteed for 2 years from the date of purchase and is subject to ACL (2) 2010 and NZ CG Act 1993 if used for personal, domestic and household use.

Installation in strict compliance with manufacturers installation.

Read more at:

- AU https://www.saniflo.com.au/cms/49/warranty-conditions
- NZ https://www.saniflo.co.nz/cms/47/warranty-conditions

WARRANTY CONDITIONS

This warranty will apply only under all of the following conditions:

- The item has been installed by a licensed plumber
- Failure is due to a fault in the manufacture of the product
- Proof of purchase (including the date of purchase) is provided
- The installation of the product is in accordance with the instructions provided.

