

# Resene Vinyl Wallpaper Sealer

Resene Vinyl Wallpaper Sealer is formulated to seal in the plasticiser found in vinyl wallpapers.

Vinyl wallpaper coated directly with standard paint finishes can become sticky as the plasticiser in the wallpaper migrates through the paint finish affecting its cure.

## interior

### Typical uses

- Wallpaper

### Physical properties

<b>Vehicle type</b>	Acrylic
<b>Solvent</b>	Isopropanol/Water/Glycol ether
<b>Dry time (minimum)</b>	Touch dry 40 minutes at 18°C
<b>Recoat time (minimum)</b>	2 hours
<b>Primer required</b>	No
<b>Theoretical coverage</b>	16-18 sq. metres per litre
<b>Dry film thickness</b>	1-2 coats (depending on application method)
<b>Abrasion resistance</b>	Very good
<b>Chemical resistance</b>	Fair
<b>Heat resistance</b>	Good
<b>Solvent resistance</b>	Good
<b>Durability</b>	Excellent, designed to be overcoated
<b>Thinning</b>	Do not thin
<b>Clean up</b>	Resene Brush Cleaner
<b>VOC</b>	617 grams per litre (see <a href="#">Resene VOC Summary</a> )

### Performance and limitations

<b>Performance</b>	<ol style="list-style-type: none"> <li>1. Seals in the plasticiser in vinyl wallpaper to avoid the sticky paint effect associated with direct overcoating of vinyl wallpapers.</li> <li>2. Provides a sound surface for overcoating with the Resene topcoats of your choice.</li> </ol>
<b>Limitations</b>	<ol style="list-style-type: none"> <li>1. Application requires good ventilation</li> <li>2. Designed to be overcoated.</li> </ol>

# Vinyl Wallpaper Sealer

## Surface preparation

Ensure surfaces to be painted are in a sound condition, dry, free from dirt, dust and loose material. Clean with a soft cloth as abrasives will damage the paper surface. Allow to dry.

Thoroughly clean down the surface to remove all loosely adhered material. Treat areas of moss or mould infestation with Resene Moss & Mould Killer (see [Data Sheet D80](#)), correctly diluted with water. Leave for up to 48 hours to achieve full kill. For heavy infestations further applications may be needed. Wash thoroughly with clean water to remove residues.

*All sanding dusts may be harmful and appropriate protection should be worn. In particular dusts from old lead or chromate based paints or old building materials containing asbestos may be injurious to health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.*

## Application

See Data Sheet D84 and Specification Sheet 16i for full instructions on coating wallpaper. Apply one full coat to seal the wallpaper. Allow to dry for two to four hours before applying the topcoat system.

If a very smooth level 5 finish is desired, apply Resene Vinyl Wallpaper Sealer. Allow to dry then skim coat the surface using Resene Broadwall Surface Prep & Seal (see [Data Sheet D807](#)) or Resene Broadwall 3 in 1 (see [Data Sheet D810](#)).

## Precautions

Maintain good ventilation throughout the drying and curing period to ensure the paint is properly cured. Poor ventilation may inhibit curing and performance.

*Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.*

**In Australia**  
PO Box 785, Ashmore City, Queensland 4214  
Call 1800 738 383, visit [www.resene.com.au](http://www.resene.com.au)  
or email [advice@resene.com.au](mailto:advice@resene.com.au)

**Resene**  
the paint the professionals use

**In New Zealand**  
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045  
Call 0800 RESENE (737 363), visit [www.resene.co.nz](http://www.resene.co.nz)  
or email [advice@resene.co.nz](mailto:advice@resene.co.nz)