

### VERTICAL SHIPLAP WEATHERBOARDS

Timber cladding solutions for the modern kiwi home.





#### TABLE OF CONTENTS

1. Introd	duction					
	ponents supplied by Smartclad					
	omponents supplied by others					
	gn considerations					
	llation information					
	ng Schedule					
Figure 1:	Vertical Shiplap - Nailed fixing					
Figure 2:	Vertical Shiplap - Base of Wall – Concrete Floor					
Figure 3:	Vertical Shiplap - Base of Wall – Timber Floor					
Figure 4:	Vertical Shiplap - Enclosed Deck – Concrete Substrate					
Figure 5:	Vertical Shiplap - Enclosed Deck – Timber Substrate					
Figure 6:	Vertical Shiplap - External 90° Corner – Boxed					
Figure 7:	Vertical Shiplap - External 90° Corner – Rebated					
Figure 8:	Vertical Shiplap - External 90° Corner – Moulding					
Figure 9:	Vertical Shiplap - External 90° Corner - Flush Moulding .					
Figure 10:	Vertical Shiplap - External 135° Corner – Boxed					
Figure 11:	Vertical Shiplap - Pipe Penetration					
Figure 12:						
Figure 13:	Vertical Shiplap - Internal 90° Corner – Flashing					
Figure 14:	Vertical Shiplap - Internal 90° Corner – Moulding					
Figure 15:	Vertical Shiplap - Internal 135° Corner – Flashing					
Figure 16:						
Figure 17:	Vertical Shiplap - Inter-Storey Cavity Junction					
Figure 18:						
Figure 19:		20				
i iyure 19.	With Wall – Butted	26				
Figure 20:	Vertical Shiplap - Parapet Balustrade Intersection With Wall – Flashing	27				
Figure 21:	Vertical Shiplap - Parapet Balustrade Intersection With Wall – Moulding	27				
Figure 22:	Vertical Shiplap - Top Of Wall - Flat Soffit	28				
Figure 23:	Vertical Shiplap - Top Of Wall - Sloping Soffit	29				
Figure 24:	Vertical Shiplap - Top of Wall – No Soffit	30				
Figure 25:	Vertical Shiplap - Top of Wall – Reverse Soffit	3				
Figure 26:	Vertical Shiplap - Window Jamb	32				
Figure 27:	Vertical Shiplap - Window Head	33				
Figure 28:	Vertical Shiplap - Window Sill	34				
Figure 29:	Vertical Shiplap - Apron Flashing	35				
Figure 30:	Vertical Shiplap - Weatherboard Join – Birdseye	36				
Figure 31:	Vertical Shiplap - Weatherboard Join	37				
7. Sma	rtClad Warranty	38				
8. Main	tenance	39				
9. Heal	th and Safety	39				
10. Discl	aimer	39				

#### ABOUT US

Purepine Mouldings Limited, manufacturers of SmartClad<sup>™</sup> Weatherboards with the hidden fixing system, is part of one of the longest established sawmilling and mouldings manufacturing operations in New Zealand.

Situated just out of Te Puke in the Bay of Plenty, the seven and a half hectare site was established back in 1958 as a moulding factory. In 1968 the sawmill operation was added. Over the years this site has been transformed from the original small factory building to a complex of buildings and yards custom made for the processes carried out on the site.

Certified plantation grown Radiata Pine is now the only species milled. Today the business is a wholly New Zealand owned family business.

#### SUSTAINABILITY

Sustainability is a vital policy for us.

We source all our logs from sustainable plantation forests found around the Bay of Plenty, Waikato and Poverty Bay and choose with great care to ensure they meet the specifications of the products required from them.



Optimising the timber to reduce wastage is vital. To this end we are use highly customised technology based systems to maximise the amount of timber we can use. Being efficient everywhere is important. A good example is the use of waste sawdust and shavings as bio fuel to produce heat for the kiln drying operation.

We believe this type of focus is paramount to sustainable outcome for future generations.

#### NZ WOOD

In a world facing dwindling resources, atmospheric pollution and global warming, wood represents our most renewable raw material, a truly natural product which can be grown and consumed indefinitely.



Collectively the forestry and wood industry is New Zealand's third largest industry contributing an enormous amount to our economy and making up over 12% of New Zealand's export earnings.

As a member of NZ Wood, Purepine Mouldings Limited's business practices are in line with those of this organisation..


2 For further information 0800 768 253 email info@smartclad.co.nz or visit www.smartclad.co.nz

#### 1. Introduction

The SmartClad<sup>™</sup> Cavity and Direct Fixed Shiplap Weatherboards are external wall claddings for use on residential and light commercial buildings, where they fall within the scope of NZ3604.

#### 2. Components supplied by Smartclad

- 2.1 Storage and preparation
  - Ensure that SmartClad<sup>™</sup> Weatherboards are correctly stored and protected prior to installation.
  - All weatherboards must be stored indoors or under a totally-weatherproof cover at all times.



- The wrap that protects SmartClad<sup>™</sup> when it is delivered is only a showerproof transit cover. It is not suitable for use as a weatherproof cover.
- It is recommended that you apply a single coat of paint to each weatherboard before installation. Choose paint with a colour that has a light reflective value (LRV) of 45% or more

2.2 SmartClad<sup>™</sup> Vertical Shiplap Weatherboards


All profiles must have a minimum 25mm overlap, with matching opposed 6 x 3mm weather grooves 10mm from the edge of each edge, and allowing for a minimum 2mm expansion gap between boards. The exposed leading edge may optionally have a 3mm pencil round finish for better paint adhesion.

#### 3. Components supplied by others

3.1 Flexible Wall Underlays and Rigid Wall Underlays — complying with Table 23 of NZBC Acceptable Solution E2/AS1 must be fitted prior to weatherboard or cavity batten installation in accordance with manufacturer's instructions.

In particular it is essential that the underlay is dressed into the window/door opening, and the flashing tapes fitted to the jambs and sills and at the corners of the opening head.

- 3.2 Building Wrap Support polypropylene strap, 75 mm galvanised mesh, galvanised wire, or additional vertical timber battens for securing the building wrap in place and preventing bulging of the bulk insulation into the drainage cavity. (Note: mesh and wire galvanising must comply with AS/ NZS 4534.)
- 3.3 Flexible Sill and Jamb Flashing Tape complying with NZBC Acceptable Solution E2/AS1 Paragraph 4.3.11, or flexible flashing tapes covered by a valid BRANZ Appraisal for use around window and door joinery openings.





- 3.4 Flashings including external corner flashing, internal corner flashing, horizontal inter-storey joint flashing, sill flashing, window and door head flashing, balustrade and parapet saddle flashing and balustrade and parapet cap flashings. Refer to NZS 3604, Section 4 and NZBC Acceptable Solution E2/AS1, Table 20 for durability requirements.
- 3.5 Cavity Base Closure (Vermin Proofing) Aluminium, stainless steel or uPVC punched with 3–5 mm diameter holes or slots complying with NZBC Acceptable Solution E2/AS1, Paragraph 9.1.8.3. Where required, flashings such as corner, sill and saddle flashings must be installed prior to weatherboard installation.
- 3.6 Window and Door Trim Cavity Air Seal air seals complying with NZBC Acceptable Solution E2/ AS1 Paragraph 9.1.6, or self-expanding, moisture cure polyurethane foam air seals covered by a valid BRANZ Appraisal suitable for use around window, door and other wall penetration openings.
- 3.7 Aluminium Joinery Head Flashings as supplied by the joinery manufacturer or building contractor.
- 3.8 Flexible Sealant sealant complying with NZBC Acceptable Solution E2/AS1, or sealant covered by a valid BRANZ Appraisal for use as a weather sealing sealant for exterior use.
- 3.9 Paint System Specification All exposed faces, including top edges at sills and all bottom edges of SmartClad<sup>™</sup> weatherboards and accessories must be finished with at least two coats of an exterior grade latex acrylic paint complying with any of Parts 7, 8, 9 or 10 of AS 3730.
- 3.10 Cavibat Cavity Batten System used with Shiplap Weatherboard Cladding

#### 4. Design considerations

- 4.1 Designer Responsibility The designer must ensure that the details contained in this manual are suitable for the intended building design and that additional detailing is provided for areas outside the scope and specifications of this manual.
- 4.2 Cavity or Direct Fix? Designers can use

the Weathertightness Risk Matrix in NZBC Acceptable Solution E2/AS1 to determine whether the cladding can be direct fixed or whether a drained and vented cavity must be incorporated into the cladding system. This manual gives details for both scenarios.

- 4.3 Scope of Use FOR ALL WEATHERBOARD PROFILES
- 4.3.1 DIRECT FIX

The SmartClad<sup>™</sup> Weatherboard range Direct Fixed Cladding System is to be used as an external vertically fixed wall cladding system for buildings within the following scope:

- a) the scope limitations of NZBC Acceptable Solution E2/ AS1, Paragraph 1.1; and,
- b) constructed with timber framing complying with the NZBC; and,
- c) calculated in accordance with NZBC Acceptable Solution E2/AS1, Table 2; and,
- d) situated in NZS 3604 Building Wind Zones up to, and including 'Very High'

In low risk situations, SmartClad<sup>™</sup> Vertical Shiplap Weatherboards can be fixed directly to the studs when the risk score is 6 or below.

For all situations where the risk score exceeds the above, cavity battens are required. These being castellated timber battens or Cavibat extruded plastic battens. Refer to BRANZ appraisal No.524 for more information.

- 4.4 Ground Clearances The ground clearances set out in NZS3604:2011 must be adhered to in all cases. The bottom edge of the weatherboards must finish a minimum of 175 above unpaved ground or minimum 100 mm above paved ground. The weatherboards must overlap the bottom plate by at least 50 mm. The bottom edges of the weatherboards must be kept clear of decks or adjacent surfaces/roof flashings at low pitch roof/ wall junctions by a minimum of 35 mm. See detail drawings.
- 4.5 Framing Timber framing must comply with NZS 3604 for buildings or parts of buildings within the scope limitations of NZS 3604. Buildings or parts of buildings outside the scope of NZS 3604 must be to a specific design in accordance with
- 4 For further information 0800 768 253 email info@smartclad.co.nz or visit www.smartclad.co.nz



NZS 3603 and AS/NZS 1170. Where specific design is required, the framing must be of at least equivalent stiffness to the framing provisions of NZS 3604. In all cases studs must be at maximum 600 mm centres. Dwangs must be fitted flush between the studs at maximum 800 mm centres. For timber framed buildings subject to specific design up to a design differential ultimate limit state (ULS) wind pressure of 2.5 kPa, the studs must be at maximum 400 centres

- 4.7 Paint Finish The use of a high quality acrylic top coat is advised. Ensure a minimum of 150 wet microns is applied. The painting must be completed not later than 45 days after installation. More paint applied will aid the performance over time.
- 4.8 For SmartClad<sup>™</sup> Weatherboards, PurePine Mouldings Limited recommends using paint with a colour which has a Light Reflective Valve (LRV) of greater than or equal to 45%.

#### 5. Installation information Vertical Shiplap Weatherboards


- 5.1 Fixings shall be driven through the wall underlay and in the framing in accordance with Table 24 E2/AS1.
  - Fixings shall be hand driven.
  - Weatherboards shall be predrilled prior to application of fixing with a drill bit slightly smaller than the fixing.
  - Nail placement shall be 35mm from the edge of the weatherboard and/or 10mm from the side of the lap.
  - The lap between boards shall be 25mm with a minimum 2mm expansion gap between boards.
  - Weathergrooves shall be lined up to form a 6 x 6mm weathergroove.
  - Nails should be applied at an upward angle so as reduce water ingress through the fixing point.
  - Weatherboard fixings shall not penetrate through the flashings under any circumstances as this may jeopardise the weather tightness of the cladding system.

5.2 Vertical weatherboard systems Cavibat

- Cavibat 45mm x 18mm x 1200 fluted polypropylene to be used when installing Vertical Shiplap
- Cavity battens may also be used in either horizontal or vertical applications above. Refer to BRANZ appraisal No. 524 for further specification information.
- Cavibat cannot be structurally fixed.

#### 5.3 Vertical Shiplap Joins

- Scarf joins shall be mitred so as to allow water run off down the face of the cladding and be made over battens with one nail on each side of the join predrilled at least 12mm from the ends. The join shall have flashing tape applied to the back of the board, shall have sealant applied to the join and be optionally covered with corrosive resistant flat soakers. Joins shall be staggered by at least 450mm.
- 5.4 Vertical Shiplap Corners
- 5.4.1 Internal Corners
  - Shall be made weather tight with hem folded 50x50 or 70x70 or 90x90 flashings according to the type of corner being used and the wind zone.
  - Shall be either:
    - a) Boards butted evenly into a 70 x 70 hem folded 'W' flashing; or
    - b) 40 x 40 internal corner with 90 x 90 hem folded flashing; or
    - c) Boards butted with D4S corner mould on top with 70 x 70 hem folded flashing.
  - A continuous bead of sealant shall be applied where mouldings meet weatherboards and neighbouring mouldings or joinery.
- 5.4.2 External Corners
  - Shall be made weather tight with hem folded 50x50 or 70x70 flashings according to the type of corner being used and the Wind Zone.
  - Shall use either:
    - a) Corner mould with 50x50 hem folded flashing; or





- b) Routed and notched together and sealed with construction adhesive; or
- Be covered with Smartclad box corner boards and 50x50 or 70x70 hem folded flashing.

(Note: only c) corner detail is suitable for Extra High wind zones)

- A continuous bead of sealant shall be applied where mouldings meet weatherboards and neighbouring mouldings or joinery.
- 5.5 Air Seals A nominal 5 to 10 mm gap must be left between the joinery reveal and the framing. A PEF backing rod is inserted and the gap sealed with a self-expanding polyurethane foam or sealant, in accordance with NZBC Acceptable Solution E2/ AS1 Paragraph 9.1.6.
- 5.6 Finishing Prior to painting the boards must be cleaned down, and any nail holes filled. The paint coating manufacturer's instructions must be followed at all times for application of the paint finish. SmartClad<sup>™</sup> weatherboards must be painted as soon as practicable following fixing. All coating is to be done according to coating manufacturer's instructions in a well-ventilated area. Refer to the coating/primer supplier for all matters relating to health and safety. All relevant sections of standard AS/NZS 2311:2009 (Guide to the painting of buildings) shall be adhered to.

All exposed faces, including top edges at sills and all bottom edges of SmartClad<sup>™</sup> weatherboards and accessories must be finished with at least two coats of an exterior grade latex acrylic paint complying with any of Parts 7, 8, 9 or 10 of AS 3730.

If SmartClad<sup>™</sup> Weatherboards are exposed to the weather for more than 60 days, they must be re-primed with one coat of alkyd primer prior to the application of the finishing coats. The recommended drying time between coats and the temperature limitations for application must be followed.

5.7 Architectural diagrams for further Vertical Shiplap fixing details. Pages: 8-39

#### 6. Nailing Schedule

- Smartclad recommends hand nailing
- Hot dip galvanising must meet the requirements of AS/NZS 4680:2006
- In sea spray zones all fittings must be type 316 stainless steel
- Use jolt head or annular grooved nails. See Table 1
- Nails must penetrate each stud by a minimum of 35mm
- E2/AS1 Acceptable Solutions states that Vertical Shiplap weatherboards can be direct fix and on risk scores of 6 or less. For use in higher risk score applications, Vertical Shiplap can be used as an Alternative Solution with horizontal cavity battens up to a risk score of 20. Horizontal cavity battens can be castellated timber batten or Cavibat plastic extruded battens
- Vertical Shiplap requires fixing the nogs at 480mm centres maximum

For Vertical Shiplap profiles, only direct fix applications are an Acceptable Solution in E2/AS1. However horizontal cavity battens can be used for cavity fix as an Alternative Solution. Two types of horizontal cavity batten can be used: catellated timber cavity batten and Cavibat.

Regular timber cavity batten cannot be used as this prevents water drainage through the cavity. Castellated cavity battens and Cavibat both have gaps that allow water to drain


- Castellated timber cavity battens are H3.1 or H3.2 treated and have gaps machined into it at approximately 100mm centres. They have a downward slope on the top at a 20° angle to assist draining water. They are to be fixed onto every nog/dwang using 40x2.5 galvanised flat head nails or 50mm galvanised brad nails
- Cavibat is an extruded polypropylene fluted cavity batten. Cavibats are installed with 40x2.8mm galvanised flat heat nails or brad gun nailed with galvanised brads at 400mm centres. Please refer to Cavibat's technical guide for full installation details

#### Table 1


Profile	Application	Size mm	Nail Size	Nail Position
Vertical Shiplap	Direct Fix	150 x 25, 200 x 25	60 x 2.8	Single nail on every nog 35mm from side of the lap
Vertical Shiplap	Cavity Fix	150 x 25, 200 x 25	75 x 3.15	Single nail on every nog 35mm from side of the lap

6 For further information 0800 768 253 email info@smartclad.co.nz or visit www.smartclad.co.nz

Preparation — 480mm centre maximum nog spacing



Set Out Guide — the required overlap is 25mm






 $\Box$ 


J

Т


#### Figure 1: Vertical Shiplap - Nailed fixing



BIRD'S EYE VIEW



BIRD'S EYE VIEW



# DIRECT F

Ú


CAVIT

S




Ъ П


C T



#### Figure 2: Vertical Shiplap - Base of Wall – Concrete Floor

#### Figure 3: Vertical Shiplap - Base of Wall - Timber Floor










 $\Box$ 

J


П








#### Figure 5: Vertical Shiplap - Enclosed Deck - Timber Substrate





-


П

¢





#### Figure 6: Vertical Shiplap - External 90° Corner - Boxed

Smartclad<sup>™</sup> pre-shaped Box Corner (male) 88x18 with 6 x 6mm weathergrooves Seal boards together with modified silicone or construction sealant Smartclad<sup>™</sup> pre-shaped Box Corner (female) 100x18 with 6 x 6mm weathergrooves Vertical Shiplap Weatherboards Wall underlay continuous around corner Wall framing



#### Figure 7: Vertical Shiplap - External 90° Corner - Rebated







Ú

ת











#### Figure 9: Vertical Shiplap - External 90° Corner - Flush Moulding





FIX DIRE

S

IRECT F




 $\Box$ 


Э П

 $\bigcirc$ 


П







#### Figure 11: Vertical Shiplap - Pipe Penetration



П

ú


CAVITY


S




 $\Box$ 


J








#### Figure 13: Vertical Shiplap - Internal 90° Corner - Flashing








 $\Box$ 


J

Π


C









#### Figure 15: Vertical Shiplap - Internal 135° Corner - Flashing






S U  $\Box$ J Π  $\bigcirc$ П






#### Figure 16: Vertical Shiplap - Meter Box Head & Sill






#### Figure 17: Vertical Shiplap - Inter-Storey Cavity Junction



NOTE: To be used to limit continuous cavities to the lesser of 2 storeys or 7 metres



NOTE: To be used to limit continuous cavities to the lesser of 2 storeys or 7 metres

П For further information 0800 768 253 email info@smartclad.co.nz or visit www.smartclad.co.nz 25


J Π


 $\bigcirc$ 

S

U








Note : Install flexible flashing tape and saddle flashing at junction with full height wall

Z = variable according to wind zone. Refer to E2/AS1 Table 7 parapet flashing to provide 50mm min. cover over weatherboards (70mm for very high wind zones)

Figure 19:Vertical Shiplap - Parapet Balustrade Intersection With Wall - Butted



#### Figure 20: Vertical Shiplap - Parapet Balustrade Intersection With Wall - Flashing






Figure 21: Vertical Shiplap - Parapet Balustrade Intersection With Wall - Moulding





C A A






J  $\Box$ J Π  $\bigcirc$ -





#### Figure 23: Vertical Shiplap - Top Of Wall - Sloping Soffit








P


 $\Box$ 

REC


\_


#### Figure 24: Vertical Shiplap - Top of Wall - No Soffit





#### Figure 25: Vertical Shiplap - Top of Wall - Reverse Soffit





DIREC

П

Ú

J


S


**z** 31















#### Figure 27: Vertical Shiplap – Window Head













С П

C

Т

#### Figure 29: Vertical Shiplap - Apron Flashing






FIX DIRECT

П

ú





BIRD'S EYE VIEW


J


C

Ъ П


 $\bigcirc$ 

-





#### Figure 31: Vertical Shiplap - Weatherboard Join



Ţ ת CAVITY .≺ FIX D \_\_\_\_ J Ш  $\bigcirc$ -1 T X





#### 7. SmartClad Warranty

#### Definitions:

"Date of Purchase" means the date on which Purepine issues an invoice for the SmartClad product.

"Licensed Building Practitioner" has the meaning prescribed by the Licensed Building Practitioner Rules made pursuant to the Building Act 2004. "Purepine" means Purepine Mouldings Limited and its assignees.

"Purepine Premium Weatherboards and SmartClad weatherboards checklist" means the checklist to be completed by the customer and returned to Purepine after the cladding is completed.

"Resistant" means resistant to the extent set out in SmartClad product literature at the time the SmartClad products were installed.

"SmartClad" means Purepine's SmartClad weatherboard cladding system, clips and preformed component products.

"SmartClad Technical Manual" means the SmartClad technical manual as updated from time to time available from Purepine's website www.smartclad.co.nz or by phoning toll-free 0800 768 253 during normal working hours.

"Warranty" means the Warranty given below under the heading "Warranty".

"Warranty Conditions" means the conditions and limitations listed below under the heading "Warranty Conditions".

#### Warranty

Subject to the Warranty Conditions, for a period of 15 years from the Date of Purchase, Purepine warrants that SmartClad will be:

- free from manufacturing and production defects;
- resistant to cracking;\*
- resistant to rotting;\*
- resistant to damage from borer attacks;\* and
- resistant to damage from termite attacks.\*

\* **Note:** "Resistant" means resistant to the extent set out in the SmartClad product literature at the time of installation.

#### Warranty Conditions

This Warranty is strictly subject to the following conditions and limitations. Failure to comply with these conditions may result, at the sole discretion of Purepine, in a Warranty claim being rejected.

#### 1 Installation

- 1.1 SmartClad must be installed by competent Licensed Building Practitioner.
- 1.2 SmartClad must be installed strictly in accordance with the SmartClad Technical Manual using only SmartClad products.

- 1.3 If the SmartClad Technical Manual does not contain the necessary installation instructions, then SmartClad must be installed in accordance with best trade practices as determined by the relevant local authority and, if prudent, as determined by the designer of the structure to which SmartClad is being installed.
- 1.4 Non-SmartClad products used in conjunction with or alongside SmartClad must be installed/ applied strictly in accordance with the relevant manufacturer's installation specifications and guidelines or best trade practice if such specifications and guidelines are not available.
- 1.5 The structure or building in which SmartClad has been incorporated must be designed and constructed in accordance with the New Zealand Building Code current at the time of installation, the Building Act 2004 and all rules, standards, and regulations issued thereunder and all consents issued by local authority for the structure.

#### 2 Maintenance

- 2.1 SmartClad must be maintained strictly as recommended by the SmartClad Technical Manual.
- 2.2 Non-SmartClad products used in conjunction with or alongside SmartClad including (but not limited to) coating and jointing systems, must be maintained strictly in accordance with the relevant manufacturers installation specifications and guidelines or best trade practice if such specifications and guidelines are not available.

#### 3 Timing of Claim

- 3.1 The Purepine Premium weatherboards and SmartClad weatherboards checklist must be completed and returned to Purepine on completion of cladding and no later than 30 days of a defect becoming apparent.
- 3.2 Claims under the Warranty must be received in writing by Purepine within 30 days of the date the deficiency or fault became or should have become apparent to a building owner acting reasonably.
- 3.3 Purepine will not be liable for claims made after the time frame specified in 3.1 has expired.
- 3.4 Except as otherwise permitted by law, and without limiting anything else contained herein, all claims against Purepine must be made through the supplier of SmartClad.

#### 4 Privity of Contract

- 4.1 The Warranty is for the benefit of the customer named on Purepine's purchase invoice only.
- 4.2 Without limiting clause 4.1, this Warranty is not transferable to subsequent owners or occupiers of the structure to which SmartClad is installed.

#### 5 Remedies

- 5.1 Upon receipt of a valid Warranty claim, Purepine will in its sole discretion elect to either:
  - 5.1.1 supply replacement SmartClad for installation by the customer; or
  - 5.1.2 undertake rectification works on the affected SmartClad; or
  - 5.1.3 pay for the cost of the replacement or rectification of the affected SmartClad.
- 5.2 Other than as specified in clause 5.1, no other remedies are available to the customer under this Warranty.
- 5.3 The customer acknowledges and agrees that replacement product and/or remedial works may result in colour variations between the original and replacement SmartClad due to the effects of weathering and changes to SmartClad materials over time. Purepine shall not be liable to the customer for any such colour variations.

#### 6 Limitation of Liability

- 6.1 Other than as stated herein, Purepine will not be liable for any losses, liabilities, costs, charges, expenses, damages whether direct, indirect or consequential, howsoever arising as a result of a defect or deficiency or fault in SmartClad.
- 6.2 For clarity, but without prejudice to the generality of clause 6.1, Purepine will specifically not be liable for any losses, liabilities, costs, charges, expenses, damages whether direct, indirect or consequential, arising from or in any way attributable to poor workmanship, poor design, poor detailing, structural settlement, structural movement, movement of materials to which SmartClad is attached, improper structural design, acts of God including but not limited to earthquakes, cyclones, floods or other severe weather conditions, efflorescence, performance of paint or coatings applied to SmartClad, normal wear and tear, growth of mould, mildew fungi, bacteria, or any attachment of any organism on the surface of SmartClad (whether on the exposed or unexposed surfaces). This Warranty does not exclude or modify any legal rights a customer may have under the Consumer Guarantees Act 1993.
- 6.3 To the fullest extent allowed by law, all warranties, conditions, liabilities and obligations expressed or implied by law other than those specifically set out in this Warranty are excluded. Without limiting the generality of the foregoing, unless otherwise specified in writing at the Date of Purchase, Purepine assumes no liability for SmartClad being fit for any particular purpose.
- 6.4 Failure to complete and return the Purepine Premium weatherboards and SmartClad weatherboards checklist may void warranty.

#### 8. Maintenance

- 7.1 Building owners are responsible for the maintenance of the SmartClad<sup>™</sup> Bevelback, Rusticated and Vertical Shiplap Weatherboard Cladding Systems.
- 7.2 Regular maintenance is essential to ensure the performance requirements of the NZBC are continually met and to ensure the maximum serviceability of the system.
- 7.3 Regular cleaning (at least annually) of the paint coating is required to remove grime, dirt and organic growth and to maximise the life and appearance of the paint. Grime may be removed by brushing with a soft brush, warm water and detergent. Paint systems must be recoated at approximately 7–10 yearly intervals in accordance with the paint manufacturer's instructions.
- 7.4 Annual inspections must be made to ensure that all aspects of the cladding system, including the paint coating system, flashings and any sealed joints remain in a weatherproof condition. Any damaged areas or areas showing signs of deterioration which would allow water ingress must be repaired immediately. Sealant and paint coatings must be repaired in accordance with the relevant manufacturer's instructions.
- 7.5 Minimum ground clearances as set out in this manual must be maintained at all times during the life of the system. (Failure to adhere to the minimum ground clearances will adversely affect the long term durability of the SmartClad<sup>™</sup> Vertical Shiplap Weatherboard Cladding Systems.)

#### 9. Health and Safety

Purepine Mouldings Limited weatherboards and timber accessories are cut with conventional hand and power tools. Cutting of boards must be carried out in well ventilated areas. Personal protective equipment such as dust masks, eye and hearing protection must be worn.

#### 10. Disclaimer

The recommendations contained in this document are based on good building practice, but are not an exhaustive statement of all relevant information. The successful performance of the system relies on many factors outside the control of Purepine Mouldings Limited such as the quality of workmanship and design.

Purepine Mouldings Limited shall not be liable for the recommendations made in its literature and the performance of the system including conformance with the NZBC, regulations and standards. It is the responsibility of the building designer to ensure that the details and recommendations provided are suitable for the intended project and that the design is executed appropriately.





For more information call the tollfree help line **0800 768 253** or visit **www.smartclad.co.nz** 



Purepine Mouldings Limited Tel: +64 7 573 9161 info@purepine.co.nz PO Box 41, Te Puke www.purepine.co.nz