

# Resene Waterborne Woodsmen Cool Colour penetrating oil stain

Resene Waterborne Woodsmen is a waterborne woodstain matching the needs of timber to the desire to achieve the most natural appearance possible. Resene Cool Colour technology performs optimally on dark colours that are the most prone to heat build-up.

## exterior

### Typical uses

- Beams
- Fences
- Plywood and profiled sheets
- Timber - dressed and rough sawn
- Weatherboards

<b>Vehicle type</b>	Oil-based waterborne
<b>Pigmentation</b>	Natural coloured oxides and limed colours
<b>Solvent</b>	Water
<b>Finish</b>	Fully penetrating over bare timber
<b>Colour</b>	Selected colours from the Resene Exterior timber stains colour chart
<b>Dry time (minimum)</b>	24 hours at 18°C
<b>Recoat time (minimum)</b>	24 hours at 18°C
<b>Primer required</b>	No
<b>Theoretical coverage</b>	Dependent on surface
<b>Usual no. of coats</b>	2 (new work - see limitations); 1-2 (old work)
<b>Thinning and clean up</b>	Do not thin; clean up with water when wet; mineral turps when dry
<b>VOC</b>	c. 81 grams per litre (see <a href="#">Resene VOC Summary</a> )

### Physical properties

### Performance

### Performance and limitations

1. Reflects heat improving the life of the woodstain finish and substrate and improving interior conditions inside the painted structure.
2. Provides a genuine rustic look.
3. Very easy application.
4. Requires minimum surface preparation.
5. Contains powerful fungicides for mould resistance.
6. An Environmental Choice approved product.

### Limitations

1. Will not kill existing mould. Use Resene Moss & Mould Killer (see [Data Sheet D80](#)).
2. Will not prevent checking of plywood.
3. Will require maintenance after two summers.
4. New dressed or dense timber may need a third coat after three months.
5. Not recommended for high contact surfaces, such as pedestrian areas and furniture.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of product. If in doubt contact Resene.



# WB Woodsman CoolColour™ penetrating oil stain

## Surface preparation

### Existing stains

Remove all the weakly adhering coating by sanding. Treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)).

### Exposed timber (greater than one week)

Remove any gross contamination and semi-detached cellulose fibres. Treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)).

### New timber

Ensure surface is dry and free from dirt, dust and loose material.

### Caution

Sanding dusts from some hardwoods are considered carcinogenic, and all old timber sanding dusts should be considered potentially harmful. Always wear an efficient dust mask.

*Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.*

## Application

Apply by brush, roller or spray. Saturate surface with Resene Waterborne Woodsman. During application stir the contents of the container frequently to ensure even distribution of colour. Aim to achieve the targeted coverage for the substrate as outlined below.

### Typical coverage

#### Badly weathered timber

First coat 3-4 square metres per litre.

Second coat 5-7 square metres per litre.

#### Dressed timber

First coat 10-12 square metres per litre.

Second coat 12-14 square metres per litre.

Apply a third coat 12-14 square metres per litre after about 3-6 months.

#### Rough sawn timber

First coat 4-6 square metres per litre.

Second coat 9-11 square metres per litre.

## Precautions

1. Will not penetrate through existing coatings or very hard latewood bands. For best results wipe excess Resene Waterborne Woodsman CoolColour off with a dry, absorbent, lint-free cloth rubbing along the grain.
2. Contains powerful fungicides. Avoid skin contact. If any skin contact occurs, wash skin thoroughly with soap and water immediately. Do not scrub the skin.
3. Avoid breathing vapour - use with adequate ventilation.

*Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.*

**In Australia**  
PO Box 785, Ashmore City, Queensland 4214  
Call 1800 738 383, visit [www.resene.com.au](http://www.resene.com.au)  
or email [advice@resene.com.au](mailto:advice@resene.com.au)

**Resene**  
the paint the professionals use

**In New Zealand**  
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045  
Call 0800 RESENE (737 363), visit [www.resene.co.nz](http://www.resene.co.nz)  
or email [advice@resene.co.nz](mailto:advice@resene.co.nz)