Jul 2006 D33

Resene Lusta-Glo

semi-gloss enamel

Resene Lusta-Glo dries to a beautiful, even, silky semi-gloss finish. Based on a tough flexible alkyd resin to give fast drying and maximum durability in all hardwearing areas.

interior

Physical properties

Vehicle type Alkyd

Pigmentation Solvent Finish

Dry time (minimum)

Theoretical coverage

Dry film thickness Usual no. of coats

Abrasion resistance

Chemical resistance

Heat resistance

Solvent resistance

Recoat time (minimum)

Titanium dioxide

Mineral turps Semi-gloss

Colour Selected F

Selected Resene Total Colour System, including BS5252, Multi-Finish, Whites & Neutrals and The Range.

4 hours at 18°C

16 hours

Primer required Yes

16 sq. metres per litre

32 microns at 16 sq. metres per litre

1-2

Very good

Fair

Good

Good

Durability Excellent

Thinning and clean up Mineral turps; thin with Resene Thinner No.9 for spray application

VOC c. 332 grams per litre (see Resene VOC Summary)

Typical uses

- Architraves
- Bathrooms
- Furniture
- Kitchens
- Laundries
- Plywood and wallboards
- Skirtings
- Timber doors
- Window frames

Performance and limitations 1. Matches full gloss enamel in surface to

- 1. Matches full gloss enamel in surface toughness, steam and scrub resistance.
- 2. Excellent intercoat and substrate adhesion.
- Resene Lusta-Glo may be applied over Resene Acrylic Undercoat (see Data Sheet D404) or used as its own undercoat over an appropriately sealed surface.
- 4. May be applied over a wide range of temperatures.

Limitations

- 1. Ensure the correct primer or sealer is used.
- Use a matching colour undercoat when using tinted Resene Lusta-Glo. Resene Acrylic Undercoat (see Data Sheet D404) is available in colours suitable for use under Resene Total Colour System colours to facilitate perfect hiding and finish.
- Due to waxes used in fibre and particle board, it is essential that Resene Quick Dry (see Data Sheet D45) is used as the first coat on these substrates.
- 4. Chalks more readily than Resene Super Gloss (see Data Sheet D32) on exterior exposure.
- 5. Drying may be affected by low temperatures and high humidity.
- 6. The final low gloss finish takes several days to develop.
- 7. May yellow in dark areas.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of product. If in doubt contact Resene.

Lusta-Glo semi-gloss enamel

Surface preparation

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease and mould.

If moss and mould are present, treat with Resene Moss & Mould Killer (see Data Sheet D80). Sand to smooth finish and dust off. Old enamels require sanding to a uniform dull finish.

Prime as per the following:

Particle board, Matai, Spotted Gum, Totara

Resene Quick Dry (see Data Sheet D45).

Soft or absorbent surfaces

Resene Broadwall Waterborne Wallboard Sealer (see Data Sheet D403) or Resene Sureseal (see Data Sheet D42). Substrates include fibrous plaster, gypsum plaster, paperfaced plasterboard, powdery surfaces.

Timber (excluding Matai, Spotted Gum, Totara)

Resene Quick Dry (see Data Sheet D45) or Resene Enamel Undercoat (see Data Sheet D44).

Varnished surfaces, laminated surfaces

Resene Waterborne Smooth Surface Sealer (see Data Sheet D47a).

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply by brush, speed brush, synthetic fibre roller or spray.

Interior - new

- 1. Prepare and prime as above.
- Apply one coat of Resene Acrylic Undercoat (see Data Sheet D404) in required colour. Allow to dry then sand lightly. Dust off.
- Apply one coat of Resene Lusta-Glo in required colour.

Interior - repaint

- 1. Prepare surface and spot prime as above.
- 2. Follow on as in (2) and (3) above, as for interior new.

Precautions

- 1. Ensure correct primer and/or sealer is used.
- 2. Fill all nailholes and cracked timber after priming.
- 3. Resene Sureseal (see Data Sheet D42) must be used where paperfaced plasterboard has yellowed due to prolonged exposure to sunlight, and in wet areas such as kitchens and bathrooms.
- 4. FLAMMABLE Keep away from heat and open flame. Keep closed when not in use.
- 5. Avoid breathing vapour use with adequate ventilation.

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.