

# Resene Ceiling Paint

## waterborne flat

Resene Ceiling Paint is recommended for use on ceilings of living rooms, bedrooms and dining rooms where a flat finish is required. A very low odour, low spatter product.

### interior

### Typical uses

- Fibrous plaster
- Paperfaced plasterboard
- Plaster glass
- Repaints

<b>Vehicle type</b>	100% acrylic
<b>Pigmentation</b>	Titanium dioxide
<b>Solvent</b>	Water
<b>Finish</b>	Flat
<b>Colour</b>	White
<b>Dry time (minimum)</b>	45 minutes at 18°C
<b>Recoat time (minimum)</b>	2 hours
<b>Sealer required</b>	Yes
<b>Theoretical coverage</b>	10 sq. metres per litre
<b>Dry film thickness</b>	34 microns at 10 sq. metres per litre
<b>Usual no. of coats</b>	1-2 coats
<b>Durability</b>	Good
<b>Thinning and clean up</b>	Water; in hot dry conditions can be thinned with up to 5% Resene Hot Weather Additive
<b>VOC</b>	c. 1 gram per litre (see <a href="#">Resene VOC Summary</a> )

### Physical properties

### Performance

### Performance and limitations

1. Inhibits mould growth.
2. Flow and build properties means that one coat is often enough to achieve complete hiding.
3. Excellent application properties with low spatter.
4. An Environmental Choice and Good Environmental Choice approved product.

### Limitations

1. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
2. Not recommended for use in bathrooms, kitchens or laundries (use Resene SpaceCote Flat – see [Data Sheet D314](#)).
3. Will not penetrate chalking and powdery surfaces.



Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of product. If in doubt contact Resene.

# Ceiling Paint waterborne flat

## Surface preparation

Ensure surface is dry and free from dirt, dust and loose material. Oil, grease and mould must be removed prior to painting. Fly spots and nicotine stains must be removed using Resene Emulsifiable Solvent Cleaner (see [Data Sheet D804](#)) or sugar soap.

Sand old glossy surfaces to provide a key for subsequent paint coats.

### New work, paperfaced plasterboard

Ensure new paperfaced plasterboard is prepared to a level of finish suitable for the specified paint finish. Resene Broadwall Surface Prep & Seal (see [Data Sheet D807](#)) or Resene Broadwall 3 in 1 (see [Data Sheet D810](#)) will be required to achieve a level 5 finish. Seal Resene Broadwall Surface Prep & Seal (see [Data Sheet D807](#)) with Resene Broadwall Waterborne Wallboard Sealer (see [Data Sheet D403](#)) or Resene Sureseal (see [Data Sheet D42](#)).

Seal bare substrates as required.

*Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.*

## Application

Stir thoroughly before use. Apply by brush, speed brush, synthetic fibre roller or spray. Apply one to two coats of Resene Ceiling Paint allowing at least two hours between coats.

## Precautions

Ensure correct sealer is used.

*Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.*

**In Australia**  
PO Box 785, Ashmore City, Queensland 4214  
Call 1800 738 383, visit [www.resene.com.au](http://www.resene.com.au)  
or email [advice@resene.com.au](mailto:advice@resene.com.au)

**Resene**  
the paint the professionals use

**In New Zealand**  
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045  
Call 0800 RESENE (737 363), visit [www.resene.co.nz](http://www.resene.co.nz)  
or email [advice@resene.co.nz](mailto:advice@resene.co.nz)